

Appendix C

Front Panel

This appendix displays the front panel of all switches covered by this guide.

Figure C-1: DCS-7020TR-48




Figure C-2: DCS-7020TR-48




Figure C-3: DCS-7020SR-24C2 and DCS-7020SRG-24C2

