

# Appendix C

## Front Panel

---

This appendix displays the front panel of all switches covered by this guide.

Figure C-1: DCS-7020SR-32C2



