

ARISTA

Troubleshooting Guide

VeloCloud SD-WAN 7.0

Version 7.0



Headquarters	Support	Sales
5453 Great America Parkway Santa Clara, CA 95054 USA +1-408-547-5500	+1-408-547-5502 +1-866-476-0000	+1-408-547-5501 +1-866-497-0000
www.arista.com/en/	support@arista.com	sales@arista.com

© Copyright 2026 Arista Networks, Inc. All rights reserved. The information contained herein is subject to change without notice. The trademarks, logos, and service marks ("Marks") displayed in this documentation are the property of Arista Networks in the United States and other countries. Use of the Marks is subject to the Arista Networks Terms of Use Policy, available at www.arista.com/en/terms-of-use. Use of marks belonging to other parties is for informational purposes only.

Contents

Chapter 1: VeloCloud SD-WAN Troubleshooting Guide.....	1
Chapter 2: Intended Audience.....	2
Chapter 3: About Remote Diagnostics.....	3
Chapter 4: Run Remote Diagnostic Tests on Edges.....	4
Chapter 5: Remote Diagnostic Tests on Edges.....	5
5.1 ARP Table Dump.....	7
5.2 Clear ARP Cache.....	9
5.3 Ping IPv6 Test.....	9
5.4 Ping Test.....	10
5.5 Traceroute.....	11
5.6 DNS Test.....	12
5.7 DNS/DHCP Service Restart.....	13
5.8 EVDSL Modem Status.....	14
5.9 Get IP Threat Reputation Test.....	15
5.10 Get URL Category and Reputation Test.....	15
5.11 Interface Status.....	16
5.12 LTE Modem Information.....	17
5.13 Flush Firewall Sessions.....	20
5.14 List Active Firewall Sessions.....	21
5.15 IPv6 Clear ND Cache.....	23
5.16 IPv6 ND Table Dump.....	24
5.17 IPv6 Route Table Dump.....	25
5.18 Flush DNS Cache.....	28
5.19 Flush Flows.....	28
5.20 Flush NAT.....	29
5.21 MY Traceroute.....	29
5.22 NAT Table Dump.....	32
5.23 List Active Flows.....	32
5.24 Show BFD/BFDv6 Peer Status.....	33
5.25 Show BFD/BFDv6 Peer Counters.....	34
5.26 Show BFD Settings.....	35
5.27 Show BFDv6 Settings.....	36
5.28 List BGP Redistributed Routes.....	36
5.29 List BGP Routes.....	37
5.30 List Routes per Prefix.....	38
5.31 Show BGP Neighbor Advertised Routes.....	39
5.32 Show BGP Neighbor Learned Routes.....	40
5.33 Show BGP Neighbor Received Routes.....	41
5.34 Show BGP Neighbor Details.....	42
5.35 Show BGP Routes per Prefix.....	43
5.36 Show BGP Summary.....	44

5.37 Show BGP Table.....	47
5.38 Show BGPv6 Neighbor Advertised Routes.....	48
5.39 Show BGPv6 Neighbor Learned Routes.....	50
5.40 Show BGPv6 Neighbor Received Routes.....	51
5.41 Show BGPv6 Neighbor Details.....	53
5.42 Show BGPv6 Routes per Prefix.....	55
5.43 Show BGPv6 Summary.....	56
5.44 Show BGPv6 Table.....	57
5.45 List OSPF Redistributed Routes.....	58
5.46 List OSPF Routes.....	59
5.47 Show OSPF Database.....	60
5.48 Show OSPF Database for E1 Self-Originate Routes.....	61
5.49 Show OSPF Neighbors.....	63
5.50 Show OSPF Route Table.....	63
5.51 Show OSPF Setting.....	64
5.52 List OSPFv3 Redistributed Routes.....	65
5.53 List OSPFv3 Routes.....	66
5.54 Show OSPFv3 Database.....	67
5.55 Show OSPFv3 Database for E1 Self-Originate Routes.....	68
5.56 Show OSPFv3 Neighbors.....	69
5.57 Show OSPFv3 Route Table.....	69
5.58 Show OSPFv3 Setting.....	70
5.59 Dump Context Logging Information.....	71
5.60 Enable or Disable Context Logging.....	72
5.61 Gateway.....	72
5.62 HA Info.....	73
5.63 List Clients.....	74
5.64 List Paths.....	75
5.65 MIBs for Edge.....	77
5.66 NTP Dump.....	77
5.67 Reset USB Modem.....	79
5.68 System Information.....	79
5.69 Route Table Dump.....	80
5.70 VPN Test.....	87
5.71 WAN Link Bandwidth Test.....	88
Chapter 6: Perform Remote Actions.....	89
Chapter 7: Diagnostic Bundles for Edges.....	91
7.1 Request Packet Capture Bundle for Edges.....	92
Packet Capture for Edges configured for High Availability.....	93
7.2 Request Diagnostic Bundle for Edges.....	94
Chapter 8: Diagnostic Bundles for Gateways.....	96
8.1 Request Packet Capture Bundle for Gateways.....	96
8.2 Request Diagnostic Bundle for Gateways.....	97
Appendix A: References.....	100
A.1 Related Documents.....	100

VeloCloud SD-WAN Troubleshooting Guide

The VeloCloud SD-WAN™ Troubleshooting Guide provides details about the logging capabilities available in Orchestrator and the most common issues and troubleshooting information for the VeloCloud SD-WAN product.

Intended Audience

The VeloCloud SD-WAN Troubleshooting Guide assists network administrators, network analysts, and IT administrators responsible for deploying, monitoring, and managing Enterprise branch network.

About Remote Diagnostics

VeloCloud Orchestrator supports bi-directional communication with the VeloCloud Edge by using WebSockets. WebSocket provides a full-duplex communication protocol over a single TCP connection. WebSockets easily support communication between a Web browser or other client applications and a Web server with much lower overhead than HTTP polling. Remote Diagnostics uses a bidirectional WebSocket connection instead of the live-mode heartbeat mechanism to improve responsiveness in the VeloCloud Orchestrator.

The WebSocket communication involves the following two WebSocket connections for passing WebSocket messages from a Web browser to a VeloCloud Edge and vice versa:

- A WebSocket connection between a Web browser (Orchestrator UI portal) and an Orchestrator. This connection is responsible for all communications with the Web browser and for setting up the system properties needed for establishing a WebSocket connection.
- Another WebSocket connection between an Orchestrator and an Edge. This connection is persistent and setup on Edge activation for processing heartbeats from the Edge and sending back responses to the Orchestrator.

While establishing WebSocket connections between a Web browser and an Edge, to ensure Web security against Distributed Denial-of-Service (DDoS) and Cross-site Request Forgery (CSRF) attacks, the Orchestrator validates the browser origin address for incoming requests, used to access the Orchestrator UI.

In most Orchestrators, the browser origin address/DNS hostname is the same as the value of the `network.public.address` system property. To support scenarios where the address used to access the Orchestrator UI from the browser is different from the value of the `network.public.address` system property, the Orchestrator introduces the following system properties for WebSocket connections:


- `network.portal.websocket.address`- Allows setting an alternate address/DNS hostname to access the UI from a browser if the browser address differs from the value of `network.public.address` system property. By default, the Orchestrator does not set the `network.portal.websocket.address` system property.
- `session.options.websocket.portal.idle.timeout`- Allows setting the total time (in seconds) that the browser WebSocket connection remains idle. By default, the browser WebSocket connection is active for 300 seconds in an idle state.

Run Remote Diagnostic Tests on Edges

VeloCloud Orchestrator allows running various Remote Diagnostic tests on a selected Edge.

1. To run Remote Diagnostics on an Edge, select the **Diagnostics** tab.

Figure 4-1: Remote Diagnostics for Edges



2. Select an Edge link.



Note: Alternatively, run the Remote Diagnostics test using the **Shortcuts** option available on the **Configure > Edges** or **Monitor > Edges** pages.

The Orchestrator establishes a connection to the Edge, and the **Remote Diagnostics** window displays all the possible Remote Diagnostics tests for the Edge.

3. Select an appropriate Remote Diagnostics test to run on the Edge, and then select **Run**.
The Orchestrator fetches diagnostic information from the Edge and displays it on the screen.

Remote Diagnostic Tests on Edges

VeloCloud Orchestrator allows running various remote diagnostics tests on a selected Edge. The remote diagnostic information contains Edge-specific logs for analysis.

This topic contains the following sections:

- [ARP Table Dump](#)
- [Clear ARP Cache](#)
- [Ping IPv6 Test](#)
- [Ping Test](#)
- [Traceroute](#)
- [DNS Test](#)
- [DNS/DHCP Service Restart](#)
- [EVDSL Modem Status](#)
- [Get IP Threat Reputation Test](#)
- [Get URL Category and Reputation Test](#)
- [Interface Status](#)
- [LTE Modem Information](#)
- [Flush Firewall Sessions](#)
- [List Active Firewall Sessions](#)
- [IPv6 Clear ND Cache](#)
- [IPv6 ND Table Dump](#)
- [IPv6 Route Table Dump](#)
- [Flush DNS Cache](#)
- [Flush Flows](#)
- [Flush NAT](#)
- [MY Traceroute](#)
- [NAT Table Dump](#)
- [List Active Flows](#)

-
- [Show BFD/BFDv6 Peer Status](#)
 - [Show BFD/BFDv6 Peer Counters](#)
 - [Show BFD Settings](#)
 - [Show BFDv6 Settings](#)
 - [List BGP Redistributed Routes](#)
 - [List BGP Routes](#)
 - [List Routes per Prefix](#)
 - [Show BGP Neighbor Advertised Routes](#)
 - [Show BGP Neighbor Learned Routes](#)
 - [Show BGP Neighbor Received Routes](#)
 - [Show BGP Neighbor Details](#)
 - [Show BGP Routes per Prefix](#)
 - [Show BGP Summary](#)
 - [Show BGP Table](#)
 - [Show BGPv6 Neighbor Advertised Routes](#)
 - [Show BGPv6 Neighbor Learned Routes](#)
 - [Show BGPv6 Neighbor Received Routes](#)
 - [Show BGPv6 Neighbor Details](#)
 - [Show BGPv6 Routes per Prefix](#)
 - [Show BGPv6 Summary](#)
 - [Show BGPv6 Table](#)
 - [List OSPF Redistributed Routes](#)
 - [List OSPF Routes](#)
 - [Show OSPF Database](#)
 - [Show OSPF Database for E1 Self-Originate Routes](#)
 - [Show OSPF Neighbors](#)
 - [Show OSPF Route Table](#)
 - [Show OSPF Setting](#)
 - [List OSPFv3 Redistributed Routes](#)
 - [List OSPFv3 Routes](#)
 - [Show OSPFv3 Database](#)

- [Show OSPFv3 Database for E1 Self-Originate Routes](#)
- [Show OSPFv3 Neighbors](#)
- [Show OSPFv3 Route Table](#)
- [Show OSPFv3 Setting](#)
- [Dump Context Logging Information](#)
- [Enable or Disable Context Logging](#)
- [Gateway](#)
- [HA Info](#)
- [List Clients](#)
- [List Paths](#)
- [MIBs for Edge](#)
- [NTP Dump](#)
- [Reset USB Modem](#)
- [System Information](#)
- [Route Table Dump](#)
- [VPN Test](#)
- [WAN Link Bandwidth Test](#)

5.1 **ARP Table Dump**

What is the purpose of this test?

Run this test to:

- Verify the IP address to MAC address binding on the LAN/WAN interfaces that are connected to the Edge on which the test is run.
- View the status of the ARP cache.

When can a user run this test?

The following are the scenarios when a user can run this test:

- Clients in the same broadcast domain are not reachable.
- Interface device not reachable.
- Next hop is not reachable.

What to check in the test output.

Run the **ARP Table Dump** test on the required Edge. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

Following is an example of the test output:

Figure 5-1: ARP Table Dump

ARP Table Dump

View the Contents of the ARP Table. This output is limited to display 1000 ARP entries.

Max Entries

Run

Test Duration: 1.002 seconds

Stale Timeout: 2min Dead Timeout: 25min Cleanup Timeout: 240min			
LAN-VLAN1			
10.0.1.25	00:ba:be:71:0d:7b	ALIVE	6s
LAN-VLAN100			
10.100.1.100	00:ba:be:71:0d:7b	ALIVE	6s
LAN-VLAN101			
10.101.1.100	00:ba:be:71:0d:7b	ALIVE	5s
GE3			
169.254.7.9	00:ba:be:16:40:2c	ALIVE	1s
169.254.7.12	00:ba:be:29:43:07	REFRESH	212s
GE4			
169.254.6.33	00:ba:be:39:a6:86	ALIVE	1s
GE5			
172.17.1.3	00:ba:be:0a:aa:e9	ALIVE	1s
172.18.1.3	00:ba:be:0a:aa:e9	ALIVE	1s
172.16.1.3	00:ba:be:0a:aa:e9	ALIVE	1s

The output is limited to displaying 1000 ARP entries. Following are the possible ARP cache statuses:

- **Alive**- Interface is reachable.
- **Dead**- Interface is not reachable.
- **Refresh**- Interface is trying to relearn the ARP.

To identify the cause for the device reachability issue:

1. In the output of the **ARP Table Dump** test, verify the ARP cache status of the interface.

If the status is of any value other than **Alive**, run the **Clear ARP Cache** test to clear the cache of the previously stored ARP value.



Note: The user can clear the ARP cache for only one interface at a time.

2. Run the **ARP Table Dump** test again to verify the IP address and the MAC address mapping on the LAN/WAN interface.
3. If the problem persists, collect Diagnostic and Packet Capture bundles and contact Arista Customer Support. See *Diagnostic Bundles for Edges with New Orchestrator UI*.

5.2 Clear ARP Cache

What is the purpose of this test?

Clears specific interface-learned ARP entries from the ARP table.


When can the user run this test?

This test is run when there are stale entries in the ARP table dump test. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Clear ARP Cache** test on the required Edge. Following is an example of the test output:

Figure 5-2: Clear ARP Cache



5.3 Ping IPv6 Test

What is the purpose of this test?

Verifies if the next hop or an IPv6 address is reachable from the interface.

When can a user run this test?

Run this test to check the following:

- IPv6 reachability
- Packet Loss
- RTT

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Ping IPv6** test on the required Edge. Check if the output displays *Reachable*. For a successful PING test, the number of packets transmitted must equal the number received. If not, capture the Interface

and Destination IP addresses to see where the packet is getting dropped. Following is an example of the test output:

Figure 5-3: Ping IPv6 Test

The screenshot shows a web-based interface for a "Ping IPv6 Test". At the top right is a blue "RUN" button. Below the title, a subtitle reads: "Run a ping IPv6 test to the any underlay destination via the selected source interface". There are two input fields: "Destination" with the value "fd00:1:1::1" and "Ping From" with the value "fd00:1:1::2 GE4 (Global Segment)" and a dropdown arrow. In the bottom right corner, it says "Test Duration: 43.023 seconds". A large white box at the bottom contains the text "fd00:1:1::1: Not Reachable".

5.4 Ping Test

What is the purpose of this test?

Run this test to check if the next hop or a destination IPv4 address is reachable from the source interface.

When can the user run this test?

Run this test if the user wants to verify the following:

- IPv4 reachability
- Packet Loss
- RTT

The user can run the **Ping** test on the required Edge by specifying the following parameters:

- **Segment** - Select the specific segment to run the **Ping** test.
- **Destination** - Specify the destination IP address or hostname to check network reachability.
- **Ping From** - Select a WAN/VLAN interface as the source interface for the selected segment.
- **Packet Size** - Specify a ping packet size in bytes. The supported range is between 36 and 1500, with the default value of 100.
- **Packet Count** - Specify the number of ping packets to send to the destination. The supported range is between 1 and 1024, with the default value of 5.
- **Interval** - Specify the ping interval in seconds. The interval determines how frequently ping packets are sent to the destination. The supported range is between 0.1 and 60, with the default value of 1 second.
- **Timeout** - Specify the time-out interval in seconds for Ping Reply. The supported range is between 1 and 300, with the default value of 1 second.
- **Don't Fragment** - Select this checkbox to prevent ping traffic fragmentation. By default, this option is disabled.
- **DSCP** - Select the Differentiated Services Code Point (DSCP) value for the ping packet from the list of supported values. The default value is 0.

- **Packet Pattern** - Specify the ping packet data pattern in hexadecimal format. The default value is 0x97A0.
- **TTL** - Specify the Time to Live (TTL) value of a ping packet. The supported value is between 1 and 64, with the default value of 64.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Verify if the output displays `Reachable`. For a successful PING test, the number of packets transmitted must be equal to the number of packets received. If not, capture the Interface and Destination IP addresses to see where the packet is getting dropped. Following is an example of the test output:

Figure 5-4: Ping Test

The screenshot shows a 'Ping Test' configuration window. At the top right is a 'RUN' button. Below the title, it says 'Run a ping test to the destination specified.' The configuration fields include:

- Segment:** Global Segment (dropdown)
- Destination:** 10.0.1.25 (text input)
- Ping From:** 10.0.1.1 VLAN-1 Global Segment (dropdown)
- Packet Count:** Default 5, range 1-1024
- Packet Size:** Default 100, range 36-1500
- Interval:** Default 1, range 0.1-60
- Timeout:** Default 1, range 1-300
- Dont Fragment:** ☐
- DSCP:** CSS (dropdown)
- Packet pattern:** Default 0x97A0
- TTL:** Default 64, range 1-64

 At the bottom right, it says 'Test Duration: 3.005 seconds'. The results section at the bottom shows:


```
10.0.1.25: Reachable
  - Min RTT: 1ms, Max RTT: 1ms, Avg RTT: 1ms
  - Success Rate: 100% (Packets transmitted: 5, Packets received: 5)
```

5.5 Traceroute

What is the purpose of this test?

- Displays the path and nodes to the destination from the Edge interface.
- Measures transit delays of packets at each hop across an Internet Protocol (IP) network.

When can the user run this test?

Run the **Traceroute** test via a Gateway or directly from any Wide Area Network (WAN) interface to the specified destination to understand routing or network reachability issues. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Traceroute** test on the required Edge by specifying the following parameters:

- **Segment** - Select the specific segment to run the **Traceroute** test.
- **Destination** - Specify the destination IP address or hostname to check network reachability.
- **Ping From** - Select a WAN/VLAN/LAG/Gateway interface as the source interface for the selected segment.

The following are examples of the test output:

Figure 5-5: Traceroute Using Gateway

The screenshot shows a web interface for running a Traceroute test. At the top, there's a title 'Traceroute' and a 'RUN' button. Below it, a description says 'Run a traceroute via the Gateway or directly out any of the WAN interfaces to the destination specified.' The 'Segment' dropdown is set to 'Global Segment'. The 'Destination' field contains '10.0.2.25'. The 'Traceroute Using' dropdown is set to 'Gateway'. A 'Test Duration: 5.006 seconds' label is on the right. The output area shows the following text:

```
traceroute to 10.0.2.25 (10.0.2.25), 30 hops max, 60 byte packets
 1 20.0.1.2 (20.0.1.2)  2.027 ms  1.915 ms  2.008 ms
 2 169.254.7.2 (169.254.7.2)  4.044 ms  4.038 ms  3.992 ms
 3 10.0.2.25 (10.0.2.25)  4.363 ms * 4.248 ms
```

Figure 5-6: Traceroute Using VLAN

The screenshot shows the same Traceroute interface as Figure 5-5, but with the 'Traceroute Using' dropdown set to 'VLAN-1 Global Segment'. The 'Destination' field now contains '10.0.1.25'. The 'Test Duration: 3.005 seconds' label is on the right. The output area shows the following text:

```
traceroute to 10.0.1.25 (10.0.1.25), 30 hops max, 60 byte packets
 1 10.0.1.25 (10.0.1.25)  0.229 ms  0.185 ms  0.141 ms
```

- Verify whether the Destination IP address is seen as the last hop.
- To measure transit delay, check the time (ms) displayed next to the IP address.
- If the Destination IP address does not appear, check the last hop seen for route reachability to both the source and the destination to resolve the routing issue.

5.6 DNS Test

What is the purpose of this test?

Run this test to confirm whether the Edge can resolve the Domain name to IP address.

When can a user run this test?

The following are the scenarios when a user can run this test:

- Domain name does not resolve.
- Name lookup error occurs.
- Name lookup error logs are seen.



Note: This test is specific to Edge DNS, not for clients located on the LAN side.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **DNS Test** on the required Edge. The following is an example of the test output:

Figure 5-7: DNS Test

Verify that the provided name resolves to an IP address. If the issue persists, check the DNS settings under the **Device** tab of the Edge configuration, and then try restarting the DNS server or check if the DNS Server is reachable.

5.7 DNS/DHCP Service Restart

What is the purpose of this test?

Run this test to restart both DNS and DHCP processes in the Edge.

When can you run this test?


- The Edge is acting as a DHCP and DNS server for the LAN network devices.
- The DNS and DHCP servers fail.
- DNS and DHCP processes get stalled.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **DNS/DHCP Service Restart** test on the required Edge. The following is an example of the test output:

Figure 5-8: DNS/DHCP Service Restart



 **Note:** Any output other than the previous indicates issues with either DNS/DHCP processes or an Orchestrator API call issue. Contact the support team.

5.8 EVDSL Modem Status

What is the purpose of this test?

Run this test to check the status of the Asymmetric Digital Subscriber Line (ADSL) or Very-high-bit-rate Digital Subscriber Line (VDSL) link.

When can you run this test?

Run this test to check the following details of the ADSL/VDSL link:

- Mode
- Uptime
- Peer MAC Address
- Status
- Link rate

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **EVDSL Modem Status** test on the required Edge. The following is an example of the test output:

Figure 5-9: DSL Status



Table 1: DSL Modem Status Column Descriptions

Field	Description
Name	The Small Form-Factor Pluggable (SFP) interface name where the link is connected.
Mode	The operational mode for each interface. If users use the interface for a DSL connection, the status lists the mode as DSL .
Vendor MAC	The MAC address of the DSL peer device.
xDSL Mode	VDSL or ADSL.
Link Time	Uptime of the link.
Status	Showtime indicates that the line is in sync.

5.9 Get IP Threat Reputation Test

What is the purpose of this test?

Run this test on the required Edge, providing the IP address to view the threat category for that IP.

When can you run this test?


Users can run this test when IP Threats are detected and obtain the threat category of the given IP.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Get IP Threat Reputation** on the required Edge. The following is an example of the test output:

Figure 5-10: Get IP Threat Detection



5.10 Get URL Category and Reputation Test

What is the purpose of this test?

Run this test on the required Edge by providing the URL to view the category and reputation score of a given URL.

When can you run this test?


Users can run this test to check the category and reputation score of a threat URL.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Get URL Category and Reputation** on the required Edge. The following is an example of the test output:

Figure 5-11: Get URL Category/Reputation



5.11 Interface Status

What is the purpose of this test?

Run this test to:

- Verify the interface's configuration and status.
- Check the packet loss situation.

When can you run this test?

Run this test to check the following:

- The link detected must be true. If it is false, then users must check the physical cabling and peer-end configuration.
- Ideally, RX and TX should be "0". If the RX and TX errors are incrementing, then try replacing the cables/SFPs. The values do not increase when users run this test twice.
- Negotiation parameter for the interface issue.
- For the Modem interface, verify if the signal quality strength is above 80% for a good wireless WAN link.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Interface Status** test on the required Edge. The following is an example of the test output:

Figure 5-12: Interface Status

Interface Status RUN

View the MAC address and connection status of physical interfaces.

Test Duration: 3.003 seconds

Routed Interfaces										
Name	MAC Address	Link Detected	IP Address	Netmask	IPv6 Address	Speed	Autonegotiation	RX errors	TX errors	Collisions
GE3	00:50:56:9C:05:28	true	169.254.9.3	255.255.255.248	1600:1:1:1:2:64	10000 Mbps, full duplex	off	0	0	0
GE4	00:50:56:9C:5D:97	true	169.254.7.10	255.255.255.248	1600:1:1:2:2:64	10000 Mbps, full duplex	off	0	0	0
GE5	00:50:56:9C:1D:C7	true	172.16.1.10	255.255.255.248	1600:1:1:3:2:64	10000 Mbps, full duplex	off	0	0	0
GE6	00:50:56:9C:18:5E	true	172.16.1.2	255.255.255.248	1600:1:1:4:2:64	10000 Mbps, full duplex	off	0	0	0
GE7	00:50:56:9C:A7:13	true	172.16.1.33	255.255.255.248	1600:1:1:5:2:64	10000 Mbps, full duplex	off	0	0	0
GE8	00:50:56:9C:1B:0C	true	169.254.12.2	255.255.255.248	1600:1:1:6:2:64	10000 Mbps, full duplex	off	0	0	0

Modem Interfaces									
Name	Link Detected	IP Address	Netmask	IPv6 Address	Signal Quality	Operator Name	RX errors	TX errors	Collisions

Switch Ports						
Name	MAC Address	Link Detected	Speed	RX errors	TX errors	Collisions
GE1	00:50:56:9C:E1:7A	true	10000 Mbps, full duplex	0	0	0
GE2	00:50:56:9C:42:A7	true	10000 Mbps, full duplex	0	0	0

5.12 LTE Modem Information

What is the purpose of this test?

Run this test to get details about the following:

- Modem
- Connection
- Location
- Signal Strength
- Status of the LTE

When can you run this test?

The following are the scenarios when users can run this test:

- Issues with LTE disconnections.
- Failure to understand the current state of LTE.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **LTE Modem Information** test on the required Edge. The following are examples of the test outputs:

- **Figure 5-13: Modem Information**

Modem Information

```
{
  "Manufacturer": "Sierra Wireless, Incorporated",
  "Model": "EM7455",
  "Modem identifier": "359073060235219",
  "Firmware Revision": "SwI9X30C_02.33.03.00 r8209 CARMD-EV-FRMWR2 2019/08/28 20 59 30",
  "Hardware Revision": "1.0",
  "Supported capabilities": "gsm-umts, lte",
  "Current capabilities": "gsm-umts, lte",
  "own number": "NA",
  "state": "connected",
  "Failed reason": "--",
  "Power state": "on",
  "current modes": "allowed 3g, 4g; preferred 4g",
  "imei": "359073060235219",
  "operator code": "311480",
  "operator name": "VZW",
  "registration state": "home",
  "signal quality(%)": "100"
}
```

Verify the following in the output:

- The Operator name must be correct.
- The signal quality must be above 70 % for better reception.
- The registration state must display the home for better speed.
- The LTE connection is active (connected state). If the system reports a disconnected status, users must investigate the failure reason immediately.

- **Figure 5-14: Connection Information**

Connection Information

```
{
  "Bearer": "Available",
  "Connected": "yes",
  "Suspended": "no",
  "Interface": "wwan0",
  "APN": "",
  "IP type": "ipv4v6",
  "user": "--",
  "password": "NA",
  "IP method": "static",
  "IP address": "100.88.59.190",
  "Gateway": "100.88.59.189",
  "DNS": "198.224.173.135",
  "MTU": "1428",
  "Stats Duration": "45390",
  "Rx bytes": "6636796",
  "Tx bytes": "34505527"
}
```

Verify the following in the output:

- Rx and Tx increment as expected.
- Assign IPv4 and IPv6 addresses to interfaces along with the necessary WAN information.

- The connected state must be "yes".
 - If the suspended state is "yes", try resetting the LTE Modem.
- **Figure 5-15: Location Information**

```
Location Information
{
  "operator code": "311",
  "operator name": "480",
  "location area code": "FFFE",
  "tracking area code": "1F07",
  "cell id": "00792D02"
}
```

Figure 5-16: Signal Information

```
Signal Information
{
  "Serving": {
    "EARFCN": "5230",
    "MCC": "311",
    "MNC": "480",
    "TAC": "7943",
    "CID": "00792D02",
    "Bd": "13",
    "D": "3",
    "U": "3",
    "SNR": "22",
    "PCI": "433",
    "RSRQ": "-6.2",
    "RSRP": "-71.4",
    "RSSI": "-48.7",
    "RXLV": "--"
  },
  "IntraFreq": {
    "PCI": "433",
    "RSRQ": "-6.2",
    "RSRP": "-71.4",
    "RSSI": "-48.7",
    "RXLV": "--"
  },
  "InterFreq": {
    "EARFCN": "2075",
    "ThresholdLow": "0",
    "ThresholdHi": "0",
    "Priority": "0",
    "PCI": "433",
    "RSRQ": "-18.7",
    "RSRP": "-128.1",
    "RSSI": "-101.6",
    "RXLV": "0"
  }
}
```

Verify whether the mode is online, and then check the "last error code" to see if the LTE is in a failed state.

- **Figure 5-17: Status Information**

```

Status Information

response: '!GSTATUS:
Current Time: 46460          Temperature: 55
Reset Counter: 1           Mode: ONLINE
System mode: LTE            PS state: Attached
LTE band: B13              LTE bw: 10 MHz
LTE Rx chan: 5230          LTE Tx chan: 23230
LTE CA state: INACTIVE      LTE SCell band:B4
LTE SCell bw:15 MHz        LTE SCell chan:2075
EMM state: Registered       Normal Service
RRC state: RRC Connected
IMS reg state: Full Srv     IMS mode: Normal

PCC RxM RSSI: -53          RSRP (dBm): -71
PCC RxD RSSI: -54          RSRP (dBm): -72
SCC RxM RSSI: -101         RSRP (dBm): -130
SCC RxD RSSI: -101         RSRP (dBm): -132
Tx Power: --              TAC: 1F07 (7943)
RSRQ (dB): -6.1           Cell ID: 00792D02 (7941378)
SINR (dB): 20.4'

```

- **Figure 5-18: Debug Information**

```

Debug Information

{
  "response": "'LTE Engineering",
  "IMSI": "311 480 753787712",
  "State": "Connected",
  "PLMN ID": "311 480",
  "PCI": "433",
  "Band": "13",
  "UL Channel": "23230",
  "DL Channel": "5230",
  "RSRP": "-71.4 dBm",
  "RSRQ": "-6.0 dB",
  "RS-SINR": "21.8 dB",
  "Tx Pwr": "0 dBm",
  "IP - internet": "IPv4 100.88.59.190 IPv6 2600 1010 B010 35B5 0 13 30A0 4A01",
  "APN": "Internet VZWINTERNET OTA vzwadmin",
  "Technology": "LTE",
  "1x Diversity": "NA",
  "QLIC": "NA",
  "PRL": "NA",
  "Chipset": "MDM9x35",
  "AMSS Version": "MPSS.BO.2.5.1.c1-00168-M9635TAAANAZM-1",
  "Device Version": "SWI9X30C_02.33.03.00 r8209 CARMD-EV-FRMWR2 2019/08/28 20 59 30",
  "Hardware Version": "40",
  "IP Address": "EVDO NA 1x NA",
  "Last Error code": "NA"
}

```

5.13 Flush Firewall Sessions

What is the purpose of this test?

This is similar to the Flush Flows options, but is specifically for the Stateful Firewall. This causes the Edge to not only flush the sessions but also actively send a TCP RST for TCP-based sessions.


When can you run this test?

To reset specific traffic flows, users can run the **Flush Firewall Sessions** test on the target Edge by entering the Source and Destination IP addresses. For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-19: Flush Firewall Sessions



Flush Firewall Sessions RUN

Flush established sessions from the firewall, which will actively end those sessions (i.e. send a TCP RST for TCP sessions). Use source and destination IP address filters to flush specific flows.

Source IP

Destination IP

Test Duration: 2.007 seconds

3 active firewall sessions have been flushed from the system.

5.14 List Active Firewall Sessions

What is the purpose of this test?

This allows users to view the current state of up to 1000 active firewall sessions. Users can filter by Source and Destination IP and Port, and Segment, to limit the number of sessions returned.



Note: To view IPv6 firewall session information, users must run the **List Active Firewall Sessions** test from the Orchestrator UI.

When can you run this test?

To verify if the session is allowed or blocked. If allowed, it displays in the output. Users can also see the current state of the session.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **List Active Firewall Sessions** test on the required Edge. The following is an example of a test output:

Figure 5-20: List Active Firewall Sessions

List Active Firewall Sessions

RUN

List active sessions in the firewall. Use source and destination IP address filters to view the exact sessions you want to see. This output is limited to a maximum of 1000 sessions.

Segment

all

Max Flows

100

Source IP/Port

e.g. 1.2.3.4

e.g. 123

Destination IP/Port

e.g. 1.2.3.5

e.g. 123

Test Duration: 1.002 seconds

Segment	Src IP	Dst IP	Protocol	Src Port	Dst Port	Application	Firewall Policy	TCP State	Bytes Sent	Bytes Rcvd	Duration (secs)
Global Segment	10.0.1.25	10.0.1.1	TCP	35760	179	bgp	AllowAny	CLOSED	258	164	0
Global Segment	10.0.1.25	10.0.1.1	UDP	49152	3784	udp	AllowAny	N/A	3796	5120	63

Users can verify denied traffic of the firewall under **Monitor > Firewall logs**.

Figure 5-21: Firewall Logs

Firewall Logs

Past 12 Hours

Aug 23, 2022, 1:57:37 AM to Aug 23, 2022, 1:57:37 PM

Q Search

CSV

Time	Segment	Edge	Action	Interface	Protocol	Source IP	Source Port	Destination IP	Destination Port	Rule	Reason	By
Aug 23, 2022, 1:56:14 PM	Global Segment	b1-edge1	DENY	VLAN 1	ICMP	10.0.1.25		8.8.8.8		Test	Rule-Action-Drop	

The Remote Diagnostics output displays the following information:

Table 2: Remote Diagnostics Field Descriptions

Field	Description
Segment	Specifies the segment in which the Edge processes the firewall session. Users can also filter the output based on a specific segment.
Src IP	Specifies the source IP that initiated the firewall session.
Dst IP	Specifies the destination IP of the firewall session.
Protocol	Specifies the protocol used by the firewall session traffic.
Src Port	Specifies the source port of the firewall session traffic.
Dst Port	Specifies the destination port of the firewall session traffic.
Application	Specifies the application that the Application engine/Deep Packet Inspection (DPI) engine identifies.
Firewall Policy	Specifies the firewall rule that the session matches among the configured firewall rules.
TCP State	Specifies the current Transmission Control Protocol (TCP) state of the session. In the output, users will see the current TCP state for each flow. There are 11 distinct TCP states as defined in <i>RFC 793</i>: • SERVER_LISTEN - indicates the initial state of the TCP FSM on the Edge. This state is not shown in the Remote Diagnostic output because it is the default state when the system creates a session for the flow's first packet. When the system detects a SYN packet, it immediately moves the flow to the SYN_SENT state. • SYN_SENT - Session moves to this state when users see a connection request SYN from the Client to the Server. • SYN_RECEIVED - indicates that the system detected a SYN+ACK packet from the server side. • ESTABLISHED - indicates a state after a 3-way handshake, completing Acknowledgement (ACK) from the Client side. Session is now ready for the data transfer phase. • CLIENT_FIN - From the ESTABLISHED state, the transition to CLIENT_FIN occurs after the system receives the FIN from the Client. In this state, only FIN or ACK retransmissions are allowed from the Client side. But on the Server side, all packets are allowed, except FIN packets, which move the state to CLOSING. • SERVER_FIN - From the ESTABLISHED state, the system transitions to the SERVER_FIN state after receiving the FIN from the Server. In this state, only FIN or ACK retransmits are allowed from the Server side. But on the Client side, all packets are allowed, except FIN packets, which move the state to CLOSING. • CLOSING - indicates that the system received a FIN (Finish) packet from both the client and the server. In this state, only SYN packets can reopen the session. • CLOSED - indicates that the system received a Reset (RST) packet from either the client or the server to terminate the connection abruptly. After the Gateway identifies this state, it drops all subsequent packets for that flow unless it detects a new SYN packet to re-establish the session.
Bytes Sent	Specifies the firewall session traffic from source IP to destination IP in Bytes.
Bytes Received	Specifies the firewall session traffic from the destination IP to the source IP in Bytes.
Duration	Specifies the age of the firewall session in seconds.

5.15 IPv6 Clear ND Cache

What is the purpose of this test?

To clear specific interface learned neighbor entries and their associated Layer 2 information, run the IPv6 Clear Neighbor Discovery (ND) cache command.

When can you run this test?

Run this test if there is a change of neighbor IP addressing or Layer 2 information. Select the interface for which the change has taken place.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?


The query should run and provide an output:

```
The ND cache has been cleared for the selected interface
```

If you see any other result, for example, `Timed out`, check the Edge status.

The following is an example of the test output:

Figure 5-22: IPv6 Clear ND Cache



IPv6 Clear ND Cache

Clear the IPv6 ND cache for a given interface.

Interface GE3

Test Duration: 1.002 seconds

The ND cache has been cleared for the selected interface.

5.16 IPv6 ND Table Dump

What is the purpose of this test?

The IPv6 Neighbor Discovery (ND) Table Dump command shows IPv6 neighbor entries and their corresponding Layer 2 information for each interface.

When can you run this test?

Run this test if you want to verify IPv6 neighbors and the corresponding Layer 2 MAC mapping information.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Following is an example of the test output:

Figure 5-23: IPv6 ND Table Dump

IPv6 ND Table Dump RUN

View the Contents of the IPv6 ND Table. This output is limited to display 1000 ND entries.

Max Entries 100

Test Duration: 1.001 seconds

IPv6 ND Cache		
GE4		
fd00:1:1:2::1	00:50:56:9c:c3:ee	REACHABLE
GE5		
fd00:1:1:3::1	00:50:56:9c:0d:3a	REACHABLE
fe80::250:56ff:fe9c:d3a	00:50:56:9c:0d:3a	STALE
GE6		
fd00:1:1:4::1	00:50:56:9c:f3:50	REACHABLE
GE3		
fe80::250:56ff:fe9c:5c2b	00:50:56:9c:5c:2b	STALE
fd00:1:1:1::1	00:50:56:9c:5c:2b	REACHABLE

The **Remote Diagnostics** output displays the following information for each interface:

- IPv6 address of the neighbor
- Corresponding Layer 2 MAC address
- Status of neighbor. The status can be any one of the following:
 - **Reachable** - This status indicates that the system recently updated the neighbor information and is currently using it for active communication.
 - **Stale** - This status indicates that the system collected neighbor information in the past but is not currently utilizing it for active traffic.

5.17 IPv6 Route Table Dump

What is the purpose of this test?

The **IPv6 Route Table Dump** command lists the entire IPv6 routing table.

When can you run this test?

Run this test if the user wants to verify the Route in the Forwarding Information Base (FIB) table of IPv6. The user can run the test by specifying any of the following options:

- **Segment**- Select the specific segment for which the user wants the system to display routes. Select "all" for all segments.
- **Prefix**- Specify the exact prefix for which the user wants the system to display routes.
- **Routes**- Select any of the following options from the drop-down menu:
 - **all**- Display all the routes for every prefix.

- **preferred**- Display the preferred route alone for each prefix (the route used for data forwarding).

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).



Note: The **Route Table Dump** command output has a limit of 16000 routes.

What to check in the test output?

Following is an example of the test output:

Figure 5-24: IPv6 Route Table Dump

Address	Segment	Remote	Type	Cost	Preference	Metric	Next-Hop Name	Next-Hop IP	Distribution Name	Loop-Hop Name	IPv6 Reachable Reason
2001:db8::1	Global Segment	2001:db8::1	Edge	0	0	0	10.0.0.1	10.0.0.1	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::2	Global Segment	2001:db8::2	Edge	0	0	0	10.0.0.2	10.0.0.2	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::3	Global Segment	2001:db8::3	Edge	0	0	0	10.0.0.3	10.0.0.3	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::4	Global Segment	2001:db8::4	Edge	0	0	0	10.0.0.4	10.0.0.4	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::5	Global Segment	2001:db8::5	Edge	0	0	0	10.0.0.5	10.0.0.5	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::6	Global Segment	2001:db8::6	Edge	0	0	0	10.0.0.6	10.0.0.6	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::7	Global Segment	2001:db8::7	Edge	0	0	0	10.0.0.7	10.0.0.7	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::8	Global Segment	2001:db8::8	Edge	0	0	0	10.0.0.8	10.0.0.8	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::9	Global Segment	2001:db8::9	Edge	0	0	0	10.0.0.9	10.0.0.9	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::a	Global Segment	2001:db8::a	Edge	0	0	0	10.0.0.10	10.0.0.10	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::b	Global Segment	2001:db8::b	Edge	0	0	0	10.0.0.11	10.0.0.11	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::c	Global Segment	2001:db8::c	Edge	0	0	0	10.0.0.12	10.0.0.12	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::d	Global Segment	2001:db8::d	Edge	0	0	0	10.0.0.13	10.0.0.13	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::e	Global Segment	2001:db8::e	Edge	0	0	0	10.0.0.14	10.0.0.14	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::f	Global Segment	2001:db8::f	Edge	0	0	0	10.0.0.15	10.0.0.15	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::10	Global Segment	2001:db8::10	Edge	0	0	0	10.0.0.16	10.0.0.16	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::11	Global Segment	2001:db8::11	Edge	0	0	0	10.0.0.17	10.0.0.17	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::12	Global Segment	2001:db8::12	Edge	0	0	0	10.0.0.18	10.0.0.18	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::13	Global Segment	2001:db8::13	Edge	0	0	0	10.0.0.19	10.0.0.19	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::14	Global Segment	2001:db8::14	Edge	0	0	0	10.0.0.20	10.0.0.20	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::15	Global Segment	2001:db8::15	Edge	0	0	0	10.0.0.21	10.0.0.21	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::16	Global Segment	2001:db8::16	Edge	0	0	0	10.0.0.22	10.0.0.22	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::17	Global Segment	2001:db8::17	Edge	0	0	0	10.0.0.23	10.0.0.23	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::18	Global Segment	2001:db8::18	Edge	0	0	0	10.0.0.24	10.0.0.24	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::19	Global Segment	2001:db8::19	Edge	0	0	0	10.0.0.25	10.0.0.25	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::1a	Global Segment	2001:db8::1a	Edge	0	0	0	10.0.0.26	10.0.0.26	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::1b	Global Segment	2001:db8::1b	Edge	0	0	0	10.0.0.27	10.0.0.27	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::1c	Global Segment	2001:db8::1c	Edge	0	0	0	10.0.0.28	10.0.0.28	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::1d	Global Segment	2001:db8::1d	Edge	0	0	0	10.0.0.29	10.0.0.29	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::1e	Global Segment	2001:db8::1e	Edge	0	0	0	10.0.0.30	10.0.0.30	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0
2001:db8::1f	Global Segment	2001:db8::1f	Edge	0	0	0	10.0.0.31	10.0.0.31	gateway1	gateway1	UP, RT, 0.0.0.0.0.0.0.0.0.0

The **Remote Diagnostics** output displays the following information:

Table 3: Remote Diagnostics Field Descriptions

Field	Description
Address	Specifies the IPv6 routes available in the table.
Segment	Specifies the segment in which the routes are available and handled by the Edge.
Netmask	Specifies the range of IPv6 addresses.
Type	Specifies the route type, such as Cloud, Edge2Edge, any (Underlay or Connected), and so on.
Cost	Specifies the route cost or metric used in the selection of route criteria.
Preference	Specifies the route preference.
Order	Specifies the order of the route.
Reachable	Specifies the status of the route: • True- Reachable • False- Not Reachable
Next Hop	Indicates the local exit interface for local routes. For overlay/remote routes, it indicates the type of next hop. For example, "Cloud gateway" for cloud routes, "Cloud VPN" for data center routes, or "edge to edge" routes, etc.
Next Hop Name	Specifies the name of the next hop device.
Destination Name	Specifies the name of the destination device.
Lost Reason	Specifies the codes for different reasons the route is lost to the next preferred route on the Edge.
(Not) Reachable Reason	Specifies the reason for the route being reachable or not reachable.



Note: An unresolved route, learned over multi-hop BGP, might point to an intermediate interface.

The following table lists the reason codes and the corresponding description:

Table 4: Reason Code Descriptions

Reason Code	Description
PR_UNREACHABLE	For overlay routes, the remote peer, whether Gateway or Edge, is unreachable.
IF_DOWN	The egress interface is down.
INVALID_IFIDX	The egress interface if-index for this route is invalid.
SLA_STATE_DOWN	The state given by IP SLA tracking is down.
HA_STANDBY	While the local Edge acts as a Standby, it marks all routes synced from the Active node as reachable to provide operational convenience.
LOCAL_MGMT	Management routes are always reachable.
LOOPBACK	The Loopback IP address is always reachable.
SELF_ROUTE	Self IP routes are always reachable.
RECUR_UNRES	The system marks recursive routes as reachable to enable recursive resolution, which provides greater operational convenience.
VPN_VIA_NAT	vpnViaNat routes are always reachable.
SLA_STATE_UP	State given by IP SLA tracking is up.
IF_RESOLVED	Egress interface is up and resolved.
PR_REACHABLE	For overlay routes, the remote peer, whether Gateway or Edge, is reachable.

5.18 Flush DNS Cache

What is the purpose of this test?

Although the system triggers a DNS cache cleanup every 10 minutes, it only removes entries with a Time-to-Live (TTL) of zero or less. The DPI-based entries are initially cached with a TTL of 24 hours and remain in the cache for at least that long, preventing new entries from being learnt. This prevents reliable DNS lookups to support domain-based business policies. The **Flush DNS Cache** test clears the cache, freeing space for new entries and ensuring domain-based business policies remain reliable.

When can you run this test?


To clear all DNS cache entries from a specific Edge, run the **Flush DNS Cache** test on that Edge. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

To confirm that the Edge has successfully cleared all DNS cache entries, users should run the **Flush DNS Cache** diagnostic test and then review the DNS table.

The following is an example of the test output:

Figure 5-25: Flush DNS Cache



5.19 Flush Flows

What is the purpose of this test?

To flush all current active sessions/specific flows in the device.

When can you run this test?

When specific traffic is not hitting the correct business policy or is having issues with the specific flow.


Run the **Flush Firewall Sessions** test on the required Edge, specifying the Source or Destination IP address or both. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Verify that the flows flushed match the flows seen. This would create a minor and temporary blip in the network.

The following is an example of the test output:

Figure 5-26: Flush Flows



5.20 Flush NAT

What is the purpose of this test?

To remove all the existing Network Address Translation (NAT) entries from the device.

When can you run this test?


Run this test if the NAT table contains an improper NAT entry or if users have NAT-related issues. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

When users flush the NAT table, the system immediately clears all active translation entries, which disrupts current traffic flows.

The following is an example of the test output:

Figure 5-27: Flush NAT



5.21 MY Traceroute

What is the purpose of this test?

MTR (My Traceroute) is a diagnostic tool that combines `Ping` and `Traceroute`. Like `Traceroute`, it discovers the path to the destination and also sends packets continuously and measures latency and packet loss, similar to `ping`.

This tool helps to diagnose the network problem by highlighting packet drop, latency, and it also helps to identify the problem location (destination or intermediate hops issue).

When can the user run this test?

Run the **MTR (My Traceroute)** test to the specified destination with configurable ports and protocols for understanding routing or network reachability issues. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **MTR (My Traceroute)** test on the required Edge by specifying the following parameters:

- **Segment** - Select the specific segment to run the **MTR (My Traceroute)** test.
- **Destination** - Specify the destination IP address or hostname to check network reachability.
- **MTR Using** - Select a WAN/VLAN/LAG interface as source interface for the selected segment. The drop-down list filters and displays interfaces bounded to the selected segment.
- **Packet Count** - Specify the count of MTR packets to be sent to the destination. The supported range is between 1 to 100, with the default value of 10.
- **Protocol** - Select the protocol (ICMP/TCP/UDP) for sending the MTR packet. The default is ICMP.
- **Source Port** - Specify the Source port for the MTR packet. This is optional for ICMP protocol.
- **Dest Port** - Specify the Destination port for the MTR packet. This is optional for ICMP protocol. The default Traceroute Destination port is 33434.
- **Path** - Select the path for the MTR traffic. The supported options are Direct, Multipath, NVS via Edge or NVS via Gateway, if configured. The default value is Direct. For NVS via Edge or NVS via Gateway, select the NVS tunnel.

Following are the examples of the test output:

Figure 5-28: MY Traceroute Using Direct Path




Figure 5-29: MY Traceroute Using Multipath





Figure 5-30: MY Traceroute Using NVS Tunnels



5.22 NAT Table Dump

What is the purpose of this test?

To verify that proper Network Address Translation (NAT) is occurring on the device.

When can you run this test?


Run this test if there are NATing issues. For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Use the Destination filter to view the exact entries in the NAT table. The output is limited to 1000 entries.

The following is an example of the test output:

Figure 5-31: NAT Table Dump



The screenshot shows the 'NAT Table Dump' test interface. It includes a 'Destination IP' filter with the example 'e.g. 1.2.3.5' and a 'Max Entries' dropdown set to '100'. A 'RUN' button is in the top right. Below the filters, a table displays NAT entries with columns: Src IP, Dest IP, Protocol, Src Port, Dest Port, NAT Src IP, and NAT Src Port. The table contains 10 rows of data. A 'Test Duration: 2.007 seconds' label is in the bottom right corner.

Src IP	Dest IP	Protocol	Src Port	Dest Port	NAT Src IP	NAT Src Port
192.168.100.225	170.114.2.58	TCP	57479	443	192.168.0.199	20001
192.168.100.225	172.217.163.206	TCP	59548	443	192.168.0.199	20001
192.168.100.225	170.114.14.75	TCP	57474	443	192.168.0.199	20001
192.168.100.225	142.250.199.101	TCP	59542	443	192.168.0.199	20001
192.168.100.225	142.250.76.101	TCP	59525	443	192.168.0.199	20001
192.168.100.225	142.250.199.101	TCP	59545	443	192.168.0.199	20004
192.168.100.225	66.170.111.53	TCP	80803	8080	192.168.0.199	20001
192.168.100.225	142.250.182.100	TCP	57673	443	192.168.0.199	20004

5.23 List Active Flows

What is the purpose of this test?

Run this test to understand the behavior of current flows.

When can you run this test?

Run this command to analyze how the VeloCloud SD-WAN routes and egresses an incoming traffic flow. For specific flow issues, users could select Source IP/Port or Destination IP/Port as filters to view that specific traffic flow. For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-32: List Active Flows

List Active Flows

Segment

all

Max Flows

100

Source IP/Port

e.g. 1.2.3.4

e.g. 123

Destination IP/Port

e.g. 1.2.3.5

e.g. 123

Test Duration: 3.011 seconds

List active flows in the system. Use source and destination IP address filters to view the exact flows you want to see. This output is limited to a maximum of 1000 flows.

Src IP	Dst IP	Segment	Protocol	Src Port	Dst Port	DSCP	Application	Link Policy	Route	Business Policy
192.168.100.225	8.8.8.8	Global Segment	UDP	57528	53	32	dns	Loadbalance	Cloud via Gateway	Network Service
192.168.100.225	8.8.8.8	Global Segment	UDP	61019	53	32	dns	Loadbalance	Cloud via Gateway	Network Service
192.168.100.225	8.8.8.8	Global Segment	UDP	58104	53	32	dns	Loadbalance	Cloud via Gateway	Network Service
192.168.100.225	8.8.8.8	Global Segment	UDP	58060	53	0	dns	Loadbalance	Cloud via Gateway	Network Service
192.168.100.225	8.8.8.8	Global Segment	UDP	58627	53	32	dns	Loadbalance	Cloud via Gateway	Network Service
192.168.100.225	74.125.68.27	Global Segment	TCP	61363	25	0	smtp	Loadbalance	Cloud via Gateway	Email bulk/DATA
192.168.100.225	142.250.77.99	Global Segment	TCP	58524	443	0	google_gen	Loadbalance	Direct to Cloud	Web
192.168.100.225	40.126.18.33	Global Segment	UDP	137	137	0	vbns	Loadbalance	Cloud via Gateway	Network Service

1. Verify if the traffic is hitting the correct business policy.
2. Verify whether the traffic LINK policy and Route are applied as configured in the business policy.
3. Verify whether the application map can identify traffic with the correct application signature.
4. If users have recently updated their Business Policy configurations, users should execute the **Flush Flows** command to ensure those changes take effect immediately.



Note: The output is limited to 1000 entries.

5.24 Show BFD/BFDv6 Peer Status

What is the purpose of this test?

Run this test to determine BFDv6 status with BFD peer. The status can be "UP" or "Down" or "Init".

When can you run this test?

- If BFD is failing to come up (or) is down.
- To check the "Local and Remote" timers.
- To check the "Diagnostics" code if BFD is down.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-33: Show BFD/BFDv6 Peer Status

Troubleshoot BFD - Show BFD / BFDv6 Peer Status

Use peer and local IPv4 or IPv6 address filters to show the status of specific BFD peers

Segment

Global Segment

Peer IP

172.16.2.9

Local IP

172.16.2.10

Json Format

☐

Test Duration: 1.001 second

BFD Peer:

peer 172.16.2.9 local-address 172.16.2.10 vrf [vc:0:1]

ID: 1384770339

Remote ID: 1015624290

Status: up

Uptime: 3 minute(s), 19 second(s)

Diagnostics: ok

Remote diagnostics: ok

Local timers:

Receive interval: 300ms

Transmission interval: 300ms

Echo transmission interval: 0ms

Remote timers:

Receive interval: 300ms

Transmission interval: 300ms

Echo transmission interval: 50ms

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

The **Remote Diagnostics** output displays the following information:

Table 5: Remote Diagnostics Field Descriptions

Field	Description
Peer	Specifies the IP address of BFD peer.
local-address	Specifies the local IPv4 or IPv6 address of the Edge interface in BFD.
ID	Specifies the ID of the BFD peer.
Remote ID	Specifies the remote ID of the BFD peer.
Status	Specifies the status of BFD peer. The status can be "UP" or "Down" or "Init".
Uptime	Specifies the time, in seconds, for how long the BFD is UP or Down.
Diagnostics/Remote Diagnostics	Specifies a reason if BFD is down.
Local timers/Remote timers	Indicates the configured Receive and Transmission interval values in milliseconds (ms). Also displays the Echo transmission interval in milliseconds (ms) if the Echo Transmission mode is activated on the peer.



Note: The Echo Transmission mode is not supported on Edge.

5.25 Show BFD/BFDv6 Peer Counters

What is the purpose of this test?

Run this test to determine the BFD packet counters (Sent/Received).

When can you run this test?

Run this test if BFD is failing to come Up (or) is Down. For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-34: Show BFD/BFDv6 Peer Counters

Troubleshoot BFD - Show BFD / BFDv6 Peer counters RUN

Use peer and local IPv4 or IPv6 address filters to show the counters of specific BFD peers

Segment	Global Segment ▼
Peer IP	172.16.2.9
Local IP	172.16.2.10
Json Format	☐

Test Duration: 1.002 seconds

```
peer 172.16.2.9 local-address 172.16.2.10 vrf [vc:0:1]
  Control packet input: 812 packets
  Control packet output: 813 packets
  Echo packet input: 0 packets
  Echo packet output: 0 packets
  Session up events: 1
  Session down events: 0
  Zebra notifications: 3
```

Select the **Json Format** checkbox if you want the test output in JSON format for automation validation.

The **Remote Diagnostics** output displays the following information:

- Count of BFD control Packets Sent/Received: if either the sent or received counter is incrementing, it indicates a problem on the non-incrementing side.
- Count of Echo packets Sent/Received. The Echo mode is not supported, so it should ideally be deactivated on the peer too.
- Count of Session Up/Down events, confirming the number of UP/Down events observed.
- Count of Zebra notifications.

5.26 Show BFD Settings

What is the purpose of this test?

To determine the BFD IPv4 settings and neighbor status.

When can you run this test?

Run this test to determine the State of the BFD IPv4, along with interval values. For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-35: Show BFD Settings



Seg ID	Peer Address	Local Address	State	Multihop	Detect Multiplier	Receive Interval	Transmit Interval
Global Segment	172.16.2.9	172.16.2.10	UP	false	3	300	300

5.27 Show BFDv6 Settings

What is the Purpose of This Test

To determine the BFD IPv6 settings and neighbor status.


When Can You Run This Test

Run this test to determine the State of the BFD IPv6, along with interval values. For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to Check in the Test Output

The following is an example of the test output:

Figure 5-36: Show BFDv6 Settings



Seg ID	Peer Address	Local Address	State	Multihop	Detect Multiplier	Receive Interval	Transmit Interval
Global Segment	fd00:2:1:3::1	fd00:2:1:3::2	UP	false	3	300	300

5.28 List BGP Redistributed Routes

What is the purpose of this test?

Run this test to list the IPv4 routes redistributed by the Edge to the BGP peers.


When can you run this test?

Run this test to check and confirm if a prefix is redistributed by the Edge to its BGP neighbors. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **List BGP Redistributed Routes** test on the required Edge. The following is an example of the test output:

Figure 5-37: List BGP Redistributed Routes



Address	Netmask	Metric Type	Next Hop IP	Interface	Seg Name	Communities
172.30.168.160	255.255.255.224	E	any	any	Global Segment	N/A
172.30.168.160	255.255.255.224	E	any	any	Global Segment	N/A
172.30.168.160	255.255.255.224	E	10.13.60.81	GE4	Global Segment	12345:4755
172.24.24.72	255.255.255.248	E	any	any	Global Segment	12345:777

The redistributed route, **Netmask** must be present in the **List BGP Redistributed** table. The redistributed route must be tagged with the expected **Metric Type**, **Next Hop IP** address, exit **Interface**, **Segment Name**, and **Community tag**.

5.29 List BGP Routes

What is the purpose of this test?

Run this test to list the entire BGP routes. Use an IPv4 or IPv6 prefix to filter specific BGP routes, or leave the prefix empty to see all the routes.

When can you run this test?

Run this test to check and confirm:

- If a prefix is received in the BGP Table.
- If a BGP prefix is allowed to redistribute into the SD-WAN overlay route table.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **List BGP Routes** test on the required Edge. The following is an example of the test output:

Figure 5-38: List BGP Routes

Troubleshoot BGP - List BGP Routes RUN

Show the specific BGP routes from neighbors, leave prefix empty to see all

Segment all

Prefix e.g. 1.2.3.5

Test Duration: 14.204 seconds

Address	Netmask	Metric Type	Next Hop IP	Advertise	Interface	Overlay Preference	Local Preference	AsPL	Communities	Reachable	Bgp Name
10.8.45.76	255.255.255.252	E	10.13.50.81	false	GE4	64	100	2	12345:4755	yes	Global Segment
10.8.53.208	255.255.255.252	E	10.13.50.81	false	GE4	64	100	2	12345:4755	yes	Global Segment
10.8.53.212	255.255.255.252	E	10.13.50.81	false	GE4	64	100	2	12345:4755	yes	Global Segment
10.8.56.176	255.255.255.252	E	10.13.50.81	false	GE4	64	100	2	12345:4755	yes	Global Segment
10.8.58.16	255.255.255.252	E	10.13.50.81	false	GE4	64	100	2	12345:4755	yes	Global Segment

Verify the following in the output:

- BGP routes received from BGP neighbors must be present in the table.
- The BGP route must have the advertise flag set to True and the reachable flag set to Yes to redistribute the received prefix into the overlay route table.
- The BGP route must be tagged with the expected **Metric Type**, **Next Hop IP** address, exit **Interface**, **Segment Name**, and **Community Tag**.

5.30 List Routes per Prefix

What is the purpose of this test?

Run this test to list all the possible routes (Overlay and Underlay routes) available in the Edge for the specific destination prefix.

When can you run this test?

Run this test to check and confirm:

- If the Edge has received both Overlay and Underlay routes (if available) for the specific destination prefix.
- The availability of the primary and secondary route paths (if available) for the specific destination prefix.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **List Routes per Prefix** test on the required Edge. The following is an example of the test output.

Figure 5-39: List Routes per Prefix

Troubleshoot BGP - List Routes per Prefix

Show all the Overlay and Underlay routes for a prefix and the details

Segment: all, Prefix: 172.31.216.0

Test Duration: 8.037 seconds

Address	Netmask	Metric Type	Next Hop IP	AsPath	Communities	Dest Name	Flags	Interface	Local Preference	Next Hop name	Overlay Preference	Seg Name	Route Type
172.31.216.0	255.255.252.0	E	any	651	N/A	HUB	OSPR	any	100	HUB	64	Global Segment	edge2edge
172.31.216.0	255.255.252.0	E	10.13.50.81	651 4750	12345:6789	N/A	SB	GE4	100	N/A	512	Global Segment	Underlay

The **List Routes per Prefix** command displays all possible route entries for the specified destination prefix, along with their associated local or overlay preferences and community tags.

Based on the route order displayed in the Orchestrator UI, you could check the availability of the primary and backup route paths for the specific destination prefix in each segment. i.e., 1st Route Entry = Best path (Primary path), 2nd Route Entry = Second Best Path, 3rd Route Entry = Third Best Path, and so on.

The **Route Type** identifies the origin of the route entry (Overlay or Underlay).

The **Next Hop IP** and **Dest Name** identify the next-hop device IP (for Underlay route types) or the Edge name (for Overlay route types), which advertised the specific route entry.

5.31 Show BGP Neighbor Advertised Routes

What is the purpose of this test?

Run this test to list the IPv4 routes the Edge advertises to the specified BGP peer.

When can you run this test?

Following are the scenarios when you can run this test:


- To check and confirm whether the Edge advertises the IPv4 prefixes to the specific BGP peer.
- If a prefix is denied by the BGP neighbor outbound filter configuration in Orchestrator, the Edge does not advertise it to that BGP neighbor.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Show BGP Neighbor Advertised Routes** test on the required Edge. The following is an example of the test output:

Figure 5-40: Show BGP Neighbor Advertised Routes



Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- The Edge must list all the advertised prefixes in the table. If a prefix is missed, verify the BGP neighbor status and the outbound filter configuration in the Orchestrator.
- A valid route is marked with the sign "*" and the best route is marked with the sign ">".
- All the prefixes must be tagged respectively with Metric (only for self-originated routes), Local Preference, Weight, Next Hop IP Address, AS-Path, and Route Origin code attributes.

5.32 Show BGP Neighbor Learned Routes

What is the purpose of this test?

Run this test to list the IPv4 prefixes accepted by the Edge from the BGP peer after applying the BGP neighbor inbound filters configured in the Orchestrator.

When can you run this test?

Following are the scenarios when you can run this test:


- To check and confirm if the Edge has accepted BGP routes learned from a neighbor.
- If a specific route is not present in the **Show BGP Neighbor Learned Routes** table, then we must verify the BGP neighbor inbound filter in the Orchestrator and run the diagnostic command **show bgp neighbor received routes** to list all the BGP routes advertised by the BGP Neighbor before applying the BGP inbound filters.

What to check in the test output?

Run the **Show BGP Neighbor Learned Routes** test on the required Edge. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

The following is an example of the test output:

Figure 5-41: Show BGP Neighbor Learned Routes



Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- The prefix learned and accepted by the Edge from its BGP neighbor must be present.
- A valid BGP route is marked with the sign "*" and the best route is marked with the sign ">".
- The output must display the total number of prefixes received and accepted by the Edge after applying the inbound filters.

5.33 Show BGP Neighbor Received Routes

What is the purpose of this test?

Run this test to list the IPv4 prefixes accepted by the Edge from the BGP peer before applying the BGP neighbor inbound filters configured in the Orchestrator.

When can you run this test?

Run this test to check and confirm that the Edge receives all the prefixes from a BGP neighbor. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Show BGP Neighbor Received Routes** test on the required Edge. The following is an example of the test output:

Figure 5-42: Show BGP Neighbor Received Routes

Troubleshoot BGP - Show BGP Neighbor Received Routes

Show all the BGP routes received from a neighbor before filters

Segment Global Segment

Neighbor IP 172.16.2.9

Json Format ☐

```
BGP table version is 0, local router ID is 1.2.0.1, vrf id 1
Default local pref 100, local AS 2
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
               i internal, r RIB-failure, S Stale, R Removed
Next hop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete

   Network        Next Hop        Metric LocPrf Weight Path
*> 1.2.0.1/32      172.16.2.9              0             1 21 i
*> 1.3.0.1/32      172.16.2.9              0             1 21 2 ?
*> 10.0.1.0/24     172.16.2.9              0             1 21 2 ?
*> 10.0.2.0/24     172.16.2.9              0             1 21 2 ?
*> 10.0.3.0/24     172.16.2.9              0             1 21 2 ?
*> 169.254.129.1/32 172.16.2.9              0             1 21 2 ?
*> 172.16.2.8/29   172.16.2.9              0             1 21 i
*> 172.16.2.16/29  172.16.2.9              0             1 21 i
```

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- The output must display the total number of prefixes received by the Edge.
- The output must list the number of BGP prefixes filtered by the inbound filters.
- The Edge must list all the received prefixes.
- If a BGP prefix is not present in the table, check the BGP neighborhood status and the list of BGP prefixes advertised by the BGP neighbor device to the Edge.

5.34 Show BGP Neighbor Details

What is the purpose of this test?

Run this test to check the BGP neighbor status and the BGP neighborhood uptime.


When can you run this test?

Run this test to check the details about a neighbor. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Show BGP Neighbor Details** test on the required Edge. The following is an example of the test output:

Figure 5-43: Show BGP Neighbor Details



Select the **Json Format** check box if you want the test output in JSON format for automation validation.

You can check the following parameters in the output:

- BGP neighborhood status
- BGP neighborhood uptime
- Local AS
- Remote AS
- Edge BGP Router ID
- Peer device BGP Router ID
- BGP Hold and Keep-alive Timers
- Neighbor capabilities

Verify the following in the output:

- Message statistics should display the number of BGP packets sent and received by the Edge.
- Check and confirm if any inbound/outbound filters are attached to the specific BGP neighbor, and the list of prefixes accepted by the Edge from the BGP neighbor after applying the inbound filters.
- Verify the source IP address/port number and the destination IP address/port number used by the Edge to establish BGP neighborhood. This can be done by looking into the local host/port and foreign host/port details.

5.35 Show BGP Routes per Prefix

What is the purpose of this test?

Run this test to verify a particular route detail in BGP.


When can you run this test?

Run this test to verify how the best path route is selected using BGP attributes. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Show BGP Routes per Prefix** test on the required Edge. The following is an example of the test output:

Figure 5-44: Show BGP Routes per Prefix



The output provides the following details:

- Best path to the routes along with all other paths.
- BGP attributes are used compare and check how the best path is chosen.

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

5.36 Show BGP Summary

What is the purpose of this test?

This test displays the BGP neighbors associated with the device.

When can you run this test?

Run this test to determine whether the BGP neighbor is up, or include neighbor details. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Show BGP Summary** test on the required Edge. The following is an example of the test output in string format:

Figure 5-45: Show BGP Summary Test Output in String Format

Troubleshoot BGP - Show BGP Summary RUN

Show the existing BGP neighbor and received routes

Json Format ☐

Test Duration: 2.005 seconds

```
Instance [vc:0:1]:

IPv4 Unicast Summary:


BGP view name [vc:0:1]
BGP router identifier 1.1.0.2, local AS number 1 vrf-id 1
BGP table version 17
RIB entries 33, using 6336 bytes of memory
Peers 1, using 22 KiB of memory

Neighbor      V      AS  MsgRcvd  MsgSent  TblVer  InQ  OutQ  Up/Down State/PfxRcd  PfxSnt
172.16.1.1    4      100     750      746      0     0     0 00:12:22      12       7

Total number of neighbors 1
```

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Figure 5-46: Show BGP Summary Test Output in Json Format



Verify the following in the output:

- **Neighbor:** Provides the IP of the peer that we used to peer in the configuration
- **V:** Indicates the version of BGP running in the device
- **AS:** Provides the remote peer AS path
- **MsgRcvd:** Number of packets BGP has received from its peer
- **MsgSent:** Number of packets BGP has sent to its peer
- **TblVer:** Provides the details of current BGP table version changes, if any
- **Inq:** Number of packets in the queue to be received from its peer
- **Outq:** Number of packets in the out queue to be sent to its peer

- `State/PfxRcd`: Indicates the state and prefix count of the BGP peers.

Table 6: State Descriptions

State	Description
Idle	BGP resources are initialized by the router. BGP inbound connection attempts are refused. BGP initiates a TCP connection to the peer.
Connect	BGP waits for the 3WHS to complete. If successful, the OPEN message is sent to the peer, and BGP moves to the OpenSent state. If unsuccessful, BGP continues to the Active state. However, if the ConnectRetry expires, BGP remains in this state, with the timer being reset and a new 3WHS being initiated.
Active	The ConnectRetry timer is reset, and BGP returns to the Connect state.
OpenSent	BGP waits for an OPEN message from its peer. Once received, BGP moves to the OpenConfirm state.
OpenConfirm	BGP waits for a keepalive message from its peer. If the message is received before the timeout expires, BGP moves to the Established state. Otherwise, BGP transitions to Idle.
Established	Both peers exchange UPDATE messages. If there is an error within any of the UPDATE messages, the BGP peer sends a NOTIFICATION message and enters the Idle state.



Note: Any other state with a number represents the number of subnets received by the BGP from its peer.

5.37 Show BGP Table

What is the purpose of this test?

To view the complete BGP table.

When can you run this test?

To verify whether the list of subnets and the next hop are as expected. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Show BGP Table** test on the required Edge. The following is an example of the test output:

Figure 5-47: Show BGP Table

Troubleshoot BGP - Show BGP Table

Show the BGP table

Segment: all

Json Format: ☐

Test Duration: 2.003 seconds

```
Instance [vc0:1]:
BGP table version is 17, local router ID is 1.1.0.2, vrf id 1
Default local pref 100, local AS 1
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
               i internal, r RIB-failure, S Stale, R Removed
Next hop codes: @NNN next hop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete

   Network      Next Hop        Metric LocPrf Weight Path
* 1.1.0.1/32    172.16.1.1          0         1 100 i
*>              0.0.0.0              0       32768 ?
*> 1.1.0.2/32    0.0.0.0              0       32768 ?
* 1.2.0.1/32    172.16.1.1          0         1 100 i
*>              0.0.0.0             90       32768 ?
*> 1.3.0.1/32    0.0.0.0             90       32768 ?
*> 10.0.1.0/24   0.0.0.0              0       32768 ?
*> 10.0.2.0/24   0.0.0.0             90       32768 ?
*> 10.0.3.0/24   0.0.0.0             90       32768 ?
*> 172.16.1.0/29 172.16.1.1          0         1 100 i
*> 172.16.1.24/29 172.16.1.1          0         1 100 i
*> 172.16.1.32/29 172.16.1.1          0         1 100 i
*> 172.16.2.0/29 172.16.1.1          0         1 100 i
*> 172.16.2.24/29 172.16.1.1          0         1 100 i
*> 172.16.2.32/29 172.16.1.1          0         1 100 i
```

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- **Network:** *> is the best path to the IP prefix. If there is no ">" before the prefix, then it is not injected into the forwarding table.
- **Next hop:** Provide the next hop IP to which the IP subnet must be sent.
- **Metric:** BGP metric is displayed.
- **Local pref:** BGP local preference, if present for a route, is displayed.
- **Weight:** The route's BGP weight is displayed.
- **Path:** BGP AS path of the route is displayed.

5.38 Show BGPv6 Neighbor Advertised Routes

What is the purpose of this test?

Run this test to list the IPv6 routes the Edge advertises to the specified BGPv6 neighbor.

When can you run this test?

The Following are the scenarios when you can run this test:

- To check and confirm whether the Edge advertises the IPv6 prefixes to the specific BGPv6 neighbor.
- If a prefix is denied by the BGPv6 neighbor outbound filter configuration in the Orchestrator, the edge does not advertise it to the specific BGPv6 neighbor.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Show BGPv6 Neighbor Advertised Routes** test on the required Edge. The following is an example of the test output:

Figure 5-48: Show BGPv6 Neighbor Advertised Routes

Troubleshoot BGPv6 - Show BGPv6 Neighbor Advertised Routes

Show the BGPv6 routes advertised to a neighbor

Segment
Global Segment ▼

Neighbor IP
fd00:2:1:3::1

Json Format

☐

```

BGP table version is 5, local router ID is 1.2.0.1, vrf id 1
Default local pref 100, local AS 2
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
               i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete

   Network        Next Hop           Metric LocPrf Weight Path
*> fd00:2:1::/64   ::                     0         32768 ?
*> fd00:2:1:3::/64 fd00:2:1:3::1         1      21 i
*> fd00:2:1:a003::/64
                        fd00:2:1:3::1         1      21 i
*> fd00:3:1::/64   ::                     4         32768 ?
*> fd00:ffff:ffff:7::1/128
                        fd00:2:1:3::1         1      21 i

Total number of prefixes 5

```

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- The Edge must list all the advertised prefixes in the table. If a prefix is missed, verify the BGPv6 neighbor status and the outbound filter configuration in the Orchestrator.
- A valid route is marked with the sign "*" and the best route is marked with the sign ">".

-
- All the prefixes must be tagged with (only for self-originated routes), Local Preference, Weight, Next Hop IP Address , AS-Path, and Route Origin code attributes.

5.39 Show BGPv6 Neighbor Learned Routes

What is the purpose of this test?

Run this test to list the IPv6 prefixes accepted by the Edge from the BGP neighbor after applying the BGP neighbor inbound filters configured in the Orchestrator.

When can you run this test?

The Following are the scenarios when you can run this test:

- To check and confirm if the Edge has accepted BGP routes learned from a neighbor.
- If a specific route is not present in the **Show BGPv6 Neighbor Learned Routes** table, then we must verify the BGPv6 neighbor inbound filter in the Orchestrator and run the diagnostic command **Show BGPv6 Neighbor Received Routes** to list all the BGP routes advertised by the BGP Neighbor before applying the BGP inbound filters.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Show BGPv6 Neighbor Learned Routes** test on the required Edge. The following is an example of the test output:

Figure 5-49: Show BGPv6 Neighbor Learned Routes

Troubleshoot BGPv6 - Show BGPv6 Neighbor Learned Routes

Show all the accepted BGPv6 routes learned from a neighbor after filters

Segment Global Segment ▾

Neighbor IP fd00:2:1:3::1

Json Format ☐

```

BGP table version is 5, local router ID is 1.2.0.1, vrf id 1
Default local pref 100, local AS 2
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
               i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete

   Network        Next Hop           Metric LocPrf Weight Path
*> fd00:2:1:3::/64  fe80::250:56ff:fe9c:3983
                               0             1 21 i
*> fd00:2:1:a003::/64
                               fe80::250:56ff:fe9c:3983
                               0             1 21 i
*> fd00:ffff:ffff:7::1/128
                               fe80::250:56ff:fe9c:3983
                               0             1 21 i

Displayed 3 routes and 5 total paths

```

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- The prefix learned and accepted by the Edge from its BGP neighbor must be present.
- A valid BGP route is marked with the sign "*" and the best route is marked with the sign ">".
- The prefix accepted by the Edge must hold the correct next-hop IP address, Metric, Local preference, Weight, and AS-path.
- The output must display the total number of prefixes received and accepted by the Edge after applying the inbound filters.

5.40 Show BGPv6 Neighbor Received Routes

What is the purpose of this test?

Run this test to list the IPv6 prefixes received by the Edge from the BGPv6 neighbor before applying the BGPv6 neighbor inbound filters configured in the Orchestrator.

When can you run this test?

Run this test to check and confirm that the Edge receives all the prefixes from a BGPv6 neighbor. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Show BGPv6 Neighbor Received Routes** test on the required Edge. The following is an example of the test output:

Figure 5-50: Show BGPv6 Neighbor Received Routes

Troubleshoot BGPv6 - Show BGPv6 Neighbor Received Routes

Show all the BGPv6 routes received from a neighbor before filters

Segment

Global Segment ▾

Neighbor IP

fd00:2:1:3::1

Json Format

☐

```
BGP table version is 0, local router ID is 1.2.0.1, vrf id 1
Default local pref 100, local AS 2
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
               i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete

   Network          Next Hop          Metric LocPrf Weight Path
*> fd00:2:1::/64    fd00:2:1:3::1              1  21 2 ?
*> fd00:2:1:3::/64  fd00:2:1:3::1              0              1  21 i
*> fd00:2:1:a003::/64
                        fd00:2:1:3::1              0              1  21 i
*> fd00:3:1::/64    fd00:2:1:3::1              1  21 2 ?
*> fd00:ffff:ffff:7::1/128
                        fd00:2:1:3::1              0              1  21 i

Total number of prefixes 5
```

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- The output must display the total number of prefixes received by the Edge.
- The output must list the number of BGPv6 prefixes filtered by the inbound filters.
- The Edge must list all the received prefixes.

- If a BGPv6 prefix is not present in the table, check the BGPv6 neighborship status and also check the list of BGPv6 prefixes advertised by the peer BGP on the neighbor device.

5.41 Show BGPv6 Neighbor Details

What is the purpose of this test?

Run this test to check the BGPv6 neighbor status and the BGPv6 neighborship uptime.

When can you run this test?

To confirm the current status of the BGPv6 neighborship and list the BGPv6 neighborship attributes. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output.

Run the **Show BGPv6 Neighbor Details** test on the required Edge. The following is an example of the test output:

Figure 5-51: Show BGPv6 Neighbor Details

Troubleshoot BGPv6 - Show BGPv6 Neighbor details

Show the details of BGPv6 neighbor

Segment	Global Segment ▾
Neighbor IP	fd00:2:1:3::1

```

BGP neighbor is fd00:2:1:3::1, remote AS 21, local AS 2, external link
Hostname: 21-3site-b2-l3switch1
  BGP version 4, remote router ID 2.2.2.2, local router ID 1.2.0.1
  BGP state = Established, up for 00:12:49
  Last read 00:00:01, Last write 00:00:01
  Hold time is 3, keepalive interval is 1 seconds
  Neighbor capabilities:
    4 Byte AS: advertised and received
  AddPath:
    IPv6 Unicast: RX advertised IPv6 Unicast and received
  Route refresh: advertised and received(old & new)
  Address Family IPv6 Unicast: advertised and received
  Hostname Capability: advertised (name: vc-edge, domain name: n/a) received (name: 21-3site-b2-l3switch1, domain name: n/a)
  Graceful Restart Capabilty: advertised and received
    Remote Restart timer is 120 seconds
  Address families by peer:
    none
  Graceful restart information:
    End-of-RIB send: IPv6 Unicast
  
```

Figure 5-52: Show BGPv6 Neighbor Details Test Output Continued

```
End-of-RIB send: IPv6 Unicast
End-of-RIB received: IPv6 Unicast
Local GR Mode : Helper*
Remote GR Mode : Helper
R bit          : False
Timers :
  Configured Restart Time(sec) : 120
  Received Restart Time(sec)   : 120
IPv6 Unicast :
  F bit          : False
  End-of-RIB Received : Yes
  End-of-RIB Send    : Yes
  EoRSentAfterUpdate : Yes
  Timers:
    Configured Stale Path Time(sec) : 360
Message statistics:
  Inq depth is 0
  Outq depth is 0

```

	Sent	Rcvd
Opens:	1	1
Notifications:	0	0
Updates:	4	4
Keepalives:	769	769
Route Refresh:	0	0
Capability:	0	0
Total:	774	774

```
Minimum time between advertisement runs is 0 seconds

For address family: IPv6 Unicast
Update group 1, subgroup 1
```

Figure 5-53: Show BGPv6 Neighbor Details Test Output Continued

```
For address family: IPv6 Unicast
Update group 1, subgroup 1
Packet Queue length 0
Inbound soft reconfiguration allowed
Community attribute sent to this neighbor(all)
3 accepted prefixes

Connections established 1; dropped 0
Last reset never
Local host: fd00:2:1:3::2, Local port: 59592
Foreign host: fd00:2:1:3::1, Foreign port: 179
Nexthop: 172.16.2.10
Nexthop global: fd00:2:1:3::2
Nexthop local: fe80::cf17:b49:ee02:2fe1
BGP connection: shared network
BGP Connect Retry Timer in Seconds: 120
Read thread: on Write thread: on
```

Verify the following in the output:

- Check the following parameters in the "BGPv6 neighbor table":
 - BGPv6 neighborship status
 - BGPv6 neighborship uptime
 - Local AS
 - Remote AS
 - Edge BGP Router ID
 - Peer device BGP Router ID
 - BGP Hold and Keep-alive Timers
 - Neighbor capabilities
- The number of BGP packets (such as Open, Notifications, Updates, Keepalives, Route Refresh, and Capability) sent and received by the Edge.
- Any inbound or outbound filters attached to the specific BGP neighbor.
- List of prefixes accepted by the Edge from the BGP neighbor after applying the inbound filters.
- The source IP address and port number, and the destination IP address/port number used by the Edge to establish BGPv6 neighborship.

5.42 Show BGPv6 Routes per Prefix

What is the purpose of this test?

Run this test to list all the possible Overlay and Underlay routes available in the Edge for the specific destination prefix.

When can you run this test?

The following are the scenarios when you can run this test:

- To check and confirm if the Edge is received for both Overlay and Underlay routes (if available) for the specific destination prefix.
- To check and confirm the availability of the primary and secondary route paths (if available) for the specific destination prefix.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Show BGPv6 Routes per Prefix** test on the required Edge. The following is an example of the test output:

Figure 5-54: Show BGPv6 Routes per Prefix



Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- The output must display all the possible route entries for the specific destination prefix with the associated local or overlay preferences and community tags.
- Based on the route order displayed in the Orchestrator, check the availability of the primary and backup route paths for the specific destination prefix in each segment.
- The **Route Type** flag must help us to identify the origin of the specific route entry (i.e., Overlay or Underlay route).
- The **Next Hop IP** and **Dest Name** flags must help us identify the next-hop device IP (for Underlay route types) or the Edge name (for Overlay route types), which advertised the specific route entry.

5.43 Show BGPv6 Summary

What is the purpose of this test?

Run this test to view the BGPv6 neighbors associated with the device.

When can you run this test?

Run this test to determine whether the BGPv6 neighbor is up, or include neighbor details. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

What to check in the test output?

Run the **Show BGPv6 Summary** test on the required Edge. The following is an example of the test output:

Figure 5-55: Show BGPv6 Summary

Troubleshoot BGPv6 - Show BGPv6 Summary

Show the existing BGPv6 neighbor and received routes

Json Format

☐

```
Instance [vc:0:1]:

IPv6 Unicast Summary:

BGP view name [vc:0:1]
BGP router identifier 1.2.0.1, local AS number 2 vrf-id 1
BGP table version 5
RIB entries 9, using 1512 bytes of memory
Peers 1, using 22 KiB of memory

Neighbor      V      AS MsgRcvd MsgSent  TblVer  InQ OutQ  Up/Down State/PfxRcd
fd00:2:1:3::1  4      21     893    893      0     0    0 00:14:47      3

Total number of neighbors 1
```

5.44 Show BGPv6 Table

What is the purpose of this test?

Run this test to view the completed BGPv6 table.

When can you run this test?

Run this test to verify the list of subnets and the next hop. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

What to check in the test output?

Run the **Show BGPv6 Table** test on the required Edge. The following is an example of the test output:

Figure 5-56: Show BGPv6 Table

Troubleshoot BGPv6 - Show BGPv6 Table

Show the BGPv6 table

Segment all

Json Format ☐

Instance [vc:0:1]:
BGP table version is 5, local router ID is 1.2.0.1, vrf id 1
Default local pref 100, local AS 2
Status codes: s suppressed, d damped, h history, * valid, > best, = multipath,
i internal, r RIB-failure, S Stale, R Removed
Nexthop codes: @NNN nexthop's vrf id, < announce-nh-self
Origin codes: i - IGP, e - EGP, ? - incomplete

Network	Next Hop	Metric	LocPrf	Weight	Path
*> fd00:2:1::/64	::	0		32768	?
*> fd00:2:1:3::/64	fe80::250:56ff:fe9c:3983	0		1	21 i
*> fd00:2:1:a003::/64	fe80::250:56ff:fe9c:3983	0		1	21 i
*> fd00:3:1::/64	::	4		32768	?
*> fd00:ffff:ffff:7::1/128	fe80::250:56ff:fe9c:3983	0		1	21 i

Displayed 5 routes and 5 total paths

5.45 List OSPF Redistributed Routes

What is the purpose of this test?

Run this test on all or selected segments to confirm if the Overlay routes and Underlay routes (Dynamic/Static/Connected) are redistributed to the Edge with the correct route metric.

When can you run this test?

Run this test in the following scenarios:

- There is an issue with route redistribution.
- LAN is unable to communicate with specific subnets over the overlay VPN.
- OSPF is configured.

- LAN router is not able to see the routes in its routing table that are received from overlay.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **List OSPF Redistributed Routes** test on the required Edge. The following is an example of the test output:

Figure 5-57: List OSPF Redistributed Routes

Troubleshoot OSPF - List OSPF Redistributed Routes RUN

Show all the routes redistributed to OSPF neighbor

Segment
segment1 ▼

Test Duration: 3.005 seconds

Address	Netmask	Metric Type	Next Hop IP	Cost	Interface	Seg Name
172.16.1.0	255.255.255.248	OE1	any	0	GE6	segment1
169.254.7.8	255.255.255.248	OE1	any	0	GE4	segment1
172.16.1.33	255.255.255.255	OE1	any	0	GE7	segment1
1.1.100.1	255.255.255.255	OE1	any	0	LO1100	segment1
172.16.1.32	255.255.255.248	OE1	any	0	GE7	segment1
169.254.7.10	255.255.255.255	OE1	any	0	GE4	segment1
169.254.9.0	255.255.255.248	OE1	any	0	GE3	segment1
172.17.1.0	255.255.255.248	OE1	any	0	GE6	segment1
10.100.1.0	255.255.255.0	OE1	any	0	br-network100	segment1
169.254.12.2	255.255.255.255	OE1	any	0	GE8	segment1
169.254.12.0	255.255.255.248	OE1	any	0	GE8	segment1
1.1.100.2	255.255.255.255	OE1	any	0	LO2100	segment1
172.17.1.2	255.255.255.255	OE1	any	0	GE6	segment1

Verify the following in the output:

- The route must be present in the OSPF redistribute table.
- The lowest cost is preferred if there are multiple routes. If the same route with cost 0 and 1 is learned, then the route with cost 0 is preferred.
- Verify the route metric. The following is the order of route type preference:
 - External routes type 1, O E1
 - External routes type 2, O E2

5.46 List OSPF Routes

What is the purpose of this test?

Run this test on all or selected segments to show the routes received from the peer LAN router.

When can you run this test?

You can run this test if the peer Edges are not able to receive OSR or DOSR routes from this Edge. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **List OSPF Routes** test on the required Edge. The following is an example of the test output:

Figure 5-58: List OSPF Routes

Troubleshoot OSPF - List OSPF Routes RUN

Show the specific OSPF routes from neighbors, leave prefix empty to see all

Segment
all

Prefix
e.g. 1.2.3.5

Test Duration: 3.005 seconds

Address	Netmask	Metric Type	Nbr ID	OSPF Cost	Overlay Preference	Advertise	Interface	Inbound	Reachable	Seg Name
172.16.1.16	255.255.255.248	O	1.1.1.2	11	64	true	GE5	learn	yes	Global Segment

Verify the following in the output:

- Verify the list of routes received from OSPF neighbors.
- Verify the cost attached to it. The lowest cost is preferred if there are multiple routes, and the same would be advertised to neighboring Edges.
- Verify the route metric. The following is the order of route type preference:
 - intra-area routes, O
 - inter-area routes, O IA
 - external routes type 1, O E1
 - external routes type 2, O E2

5.47 Show OSPF Database

What is the purpose of this test?

Run this test on all or selected segments to verify if the OSPF database is equivalent to show ip ospf database.


When can you run this test?

You can run this test when the OSPF database contains all LSAs that describe the network topology. The OSPF database output displays the content of the LSDB and verifies information about specific LSAs. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Show OSPF Database** test on the required Edge. The following is an example of the test output:

Figure 5-59: Show OSPF Database



Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- Verify the subnet and its advertising router if there is any asymmetric routing issue or if a different path is taken than expected.
- Verify age if there are route flaps.
- Verify that the Peer database and Edge database match; if there are any issues with the DB, the OSPF.

5.48 Show OSPF Database for E1 Self-Originate Routes

What is the purpose of this test?

This test provides the list of E1 self-originated routes.

When can you run this test?

Run this test on all or selected segments to troubleshoot routing issues with E1 type self-originated routes. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Show OSPF Database for E1 Self-Originate Routes** test on the required Edge. The following is an example of the test output:

Figure 5-60: Show OSPF Database for E1 Self-Originate Routes

Troubleshoot OSPF - Show OSPF Database for E1 Self-Originate Routes Run

Show the E1 LSA's self-originated by the VCE that are advertised to OSPF

Segment
segment1

Json Format ☐

Test Duration: 2.003 seconds

VRF Name: vc-1

```
OSPF Router with ID (1.1.100.2)

  AS External Link States

LS age: 1630
Options: 0x2 : *[-]-[-]-[-]E[-]
LS Flags: 0xb
LS Type: AS-external-LSA
Link State ID: 0.0.0.0 (External Network Number)
Advertising Router: 1.1.100.2
LS Seq Number: 80000097
Checksum: 0x56fd
Length: 36

Network Mask: /0
Metric Type: 1
TOS: 0
Metric: 0
Forward Address: 0.0.0.0
External Route Tag: 0

LS age: 1628
Options: 0x2 : *[-]-[-]-[-]E[-]
LS Flags: 0xb
LS Type: AS-external-LSA
Link State ID: 1.1.100.1 (External Network Number)
Advertising Router: 1.1.100.2
LS Seq Number: 80000099
Checksum: 0xd4bc
Length: 36

Network Mask: /32
Metric Type: 1
TOS: 0
Metric: 0
Forward Address: 0.0.0.0
External Route Tag: 0

LS age: 1628
Options: 0x2 : *[-]-[-]-[-]E[-]
LS Flags: 0xb
LS Type: AS-external-LSA
Link State ID: 1.1.100.2 (External Network Number)
Advertising Router: 1.1.100.2
LS Seq Number: 80000099
Checksum: 0xd415
Length: 36

Network Mask: /32
Metric Type: 1
TOS: 0
Metric: 0
Forward Address: 0.0.0.0
External Route Tag: 0

LS age: 1628
Options: 0x2 : *[-]-[-]-[-]E[-]
LS Flags: 0xb
LS Type: AS-external-LSA
Link State ID: 10.100.1.0 (External Network Number)
Advertising Router: 1.1.100.2
LS Seq Number: 80000099
Checksum: 0x36d2
Length: 36

Network Mask: /24
Metric Type: 1
TOS: 0
Metric: 0
Forward Address: 0.0.0.0
External Route Tag: 0
```

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- The LSA type is set to external LSA.
- The Advertising router should be the router that originates this route.
- For the LS age, check for any advertising issues.

5.49 Show OSPF Neighbors

What is the purpose of this test?

This test indicates if there are issues with OSPF neighbors.

When can you run this test?

Run this test on all or selected segments when there is an OSPF neighborship formation issue. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Show OSPF Neighbors** test on the required Edge. The following is an example of the test output:

Figure 5-61: Show OSPF Neighbors

Troubleshoot OSPF - Show OSPF Neighbors RUN

Show all the OSPF neighbors and associated info

Segment
Global Segment

Json Format
☐

Test Duration: 2.003 seconds

Neighbor ID	Pri	State	UpTime	Dead Time	Address	Interface	RxmtL	RqstL	DBsmL
1.1.1.2	1	Full/DR	30m56s	38.754s	172.16.1.9	GE5:172.16.1.10	0	0	0

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

Verify the following in the output:

- Verify if the state of the neighbor is Full/(DR or BDR). If this state is not seen, then there is an issue with OSPF neighbors' convergence.
- Down state, Attempt/Init state would be seen if you have sent/received an OSPF hello packet. If the neighbor is in this state for too long, verify the Area ID, Neighbor ID, Router ID, and OSPF configuration.
- If it is stuck between a 2-way state or an Ext start state, verify the MTU issues.
- RxmtL is the LSA retransmission list. This value is used when retransmitting Database Description and Link State Request packets. The default value is 5 seconds. If you see any values, then there is a DBD packet exchange issue in transit. Ideally, it should not be too high. Verify transit path.
- DBsmL is a database summary list for the neighbor.
- RqstL is Link State Request List.

5.50 Show OSPF Route Table

What is the purpose of this test?

Run this test on all or selected segments to verify routes and their views of the OSPF protocol.

When can you run this test?

Run this test to verify how routes are learnt on the OSPF table. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Show OSPF Route Table** test on the required Edge.

Select the **Json Format** check box if you want the test output in JSON format for automation validation.

The following is an example of the test output:

Figure 5-62: Show OSPF Route Table



5.51 Show OSPF Setting

What is the purpose of this test?

Run this test to verify if the OSPF configuration is pushed properly from Edge to Orchestrator.

When can you run this test?

Run this test to verify the Edge OSPF configuration. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the **Show OSPF Setting** test on the required Edge. The following is an example of the test output:

Figure 5-63: Show OSPF Setting

Troubleshoot OSPF - Show OSPF Setting RUN

Show OSPF setting and neighbor status

Test Duration: 1.001 seconds

Area	Network Info	Authentication	Cost	Hello Timer	Dead Timer	Interface	MD5	MTU	Nbr Addr	Nbr ID	NBR Status	OSPF	Passive Interface
0	192.118.251.42	0	1	10	40	GE0	0	1500	192.118.251.42	172.25.112.252	Full	enabled	no
0	192.118.251.76	0	1	10	40	GE0	0	1500	192.118.251.76	172.25.112.253	Full	enabled	no

Verify the following in the output:

- Verify if the Edge has the configuration like area ID, network, authentication cost, and hello timer pushed from the Orchestrator if you have customer OSPF settings.

5.52 List OSPFv3 Redistributed Routes

What is the purpose of this test?

Run this test on all or selected segments to view all the routes redistributed to the OSPFv3 neighbor.

When can you run this test?

Run this test to verify OSPFv3 redistributed routes. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the List OSPFv3 Redistributed Routes on the required Edge. The following is an example of the test output:

Figure 5-64: List OSPFv3 Redistributed Routes

Troubleshoot OSPFv3 - List OSPFv3 Redistributed Routes

RUN

Show all the routes redistributed to OSPFv3 neighbor

Segment

segment1

Test Duration: 3.006 seconds

Address	Netmask	Metric Type	Next Hop IP	Cost	Interface	Seg Name
1000:1:1:5:2	ffff:ffff:ffff:ffff	OE1	any	0	GE7	segment1
1000:1:2:4:	ffff:ffff:	OE1	any	0	GE8	segment1
1000:1:2:3:	ffff:ffff:	OE1	any	0	GE5	segment1
1000:1:1:2:2	ffff:ffff:ffff:ffff	OE1	any	0	GE4	segment1
1000:1:1:2	ffff:ffff:ffff:ffff	OE1	any	0	LO1100	segment1
1000:1:1:6:2	ffff:ffff:ffff:ffff	OE1	any	0	GE8	segment1
1000:1:1:1:2	ffff:ffff:ffff:ffff	OE1	any	0	GE3	segment1
1000:1:2:5:2	ffff:ffff:ffff:ffff	OE1	any	0	GE7	segment1
1000:1:1:2:2	ffff:ffff:ffff:ffff	OE1	any	0	LO2100	segment1
1000:1:1:4:	ffff:ffff:	OE1	any	0	GE8	segment1
1000:1:2:	ffff:ffff:	OE1	any	0	br-network100	segment1
1000:1:2:5:	ffff:ffff:	OE1	any	0	GE7	segment1
1000:1:1:1:	ffff:ffff:	OE1	any	0	GE3	segment1
1000:1:1:4:2	ffff:ffff:ffff:ffff	OE1	any	0	GE8	segment1
1000:1:1:6:	ffff:ffff:	OE1	any	0	GE8	segment1
1000:1:2:3:2	ffff:ffff:ffff:ffff	OE1	any	0	GE5	segment1
1000:1:1:2:	ffff:ffff:	OE1	any	0	GE4	segment1
1000:1:1:5:	ffff:ffff:	OE1	any	0	GE7	segment1
1000:1:2:a00:	ffff:ffff:	OE2	1000:250:500:107:44aa	11	GE5	segment1
1000:1:2:4:2	ffff:ffff:ffff:ffff	OE1	any	0	GE6	segment1

5.53 List OSPFv3 Routes

What is the purpose of this test?

Run this test on all or selected segments to view the OSPFv3 routes learned from OSPFv3 neighbors for the specified Prefix. Displays all the OSPFv3 routes from the neighbors if the Prefix is not specified. This test displays OSPFv3 routes with actions such as an inbound filter with Overlay Flow Control from Orchestrator applied.

When can you run this test?

Run this test to verify OSPFv3 Routes. For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the OSPFv3 Routes on the required Edge. The following is an example of the test output:

Figure 5-65: List OSPFv3 Routes

Troubleshoot OSPFv3 - List OSPFv3 Routes RUN

Show the specific OSPFv3 routes from neighbors, leave prefix empty to see all

Segment
all

Prefix
e.g. fd00:11:a003:1

Test Duration: 3.005 seconds

Address	Netmask	Metric Type	Nbr ID	OSPF Cost	Overlay Preference	Advertise	Interface	Inbound	Reachable	Seg Name
fd00:11:a003::	ffff:ffff::	O	0.0.0.0	11	1001	true	GE5	learn	yes	Global Segment
fd00:12:a003::	ffff:ffff::	O	0.0.0.0	11	1001	true	GE5/100	learn	yes	segment1

5.54 Show OSPFv3 Database

What is the purpose of this test?

Run this test on all or selected segments to view the OSPFv3 link state database summary.

When can you run this test?

Run this test to verify the OSPFv3 link state database. For instructions, see [Run Remote Diagnostic Tests on Edges](#).


What to check in the test output?

Run the OSPFv3 link state database on the required Edge.

Select the **JSON Format** checkbox if users want the test output in JSON format for automated validation.

The following is an example of the test output:

Figure 5-66: Show OSPFv3 Database



5.55 Show OSPFv3 Database for E1 Self-Originate Routes

What is the purpose of this test?

Run this test on all or selected segments to view the E1 LSA's self-originated routes that are advertised to OSPFv3 router by the Edge.

When can you run this test?

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the E1 LSA's self-originated routes that are advertised to the OSPFv3 router by the Edge.
Select the **JSON Format** checkbox if the user wants the test output in JSON format for automation validation.

The following is an example of the test output:

Figure 5-67: Show OSPFv3 Database for E1 Self-Originate Routes

Troubleshoot OSPFv3 - Show OSPFv3 Database for external Self-Originated Routes RUN

Show the external LSAs self-originated by the VCE that are advertised to OSPFv3

Segment
segment1

Json Format
☐

Test Duration: 2.004 seconds

AS Scoped Link State Database

Type	LSId	AdvRouter	Age	SeqNum	Payload
ASE	0.0.0.1	1.1.100.2	974	80000093	fd00:1:2::/64
ASE	0.0.0.2	1.1.100.2	974	80000093	fd00:ffff:ffff:1::2/128
ASE	0.0.0.3	1.1.100.2	974	80000093	fd00:ffff:ffff:2::2/128

5.56 Show OSPFv3 Neighbors

What is the purpose of this test?

Run this test on all or selected segments to view all the OSPFv3 neighbors and associated information.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run OSPFv3 neighbors on the required Edge. Select the **JSON Format** checkbox to receive the test output in JSON format for automation validation.

The following is an example of the test output:

Figure 5-68: Show OSPFv3 Neighbors

Troubleshoot OSPFv3 - Show OSPFv3 Neighbors RUN

Show all the OSPFv3 neighbors and associated info

Segment
all

Json Format
☐

Test Duration: 3.005 seconds

Neighbor ID	Pri	DeadTime	State/IfState	Duration I/F[State]
1.1.1.2	1	00:00:37	Full/DR	00:48:43 GE5[BDR]
Neighbor ID	Pri	DeadTime	State/IfState	Duration I/F[State]
1.1.1.2	1	00:00:37	Full/DR	00:48:43 GE5:100[BDR]

5.57 Show OSPFv3 Route Table

What is the purpose of this test?

Run this test on all or selected segments to view the existing OSPFv3 route table, which displays OSPFv3 information from both learned and redistributed routes.

When can you run this test?

Run this test to view the existing OSPFv3 route table.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Run the OSPFv3 route table on the required Edge. Select the **JSON Format** checkbox to receive the test output in JSON format for automation validation.

The following is an example of the test output:

Figure 5-69: Show OSPFv3 Route Table

Troubleshoot OSPFv3 - Show OSPFv3 Route Table RUN

Show the existing OSPFv3 route table

Segment
all

Json Format
☐

Test Duration: 2.002 seconds

```
*N IA f000:1:1:3::/64      ::                GES 00:50:45
*N IA f000:1:1:a003::/64    fe80::250:56ff:fe97:44ee GES 00:50:45
*N IA f000:1:2:3::/64      ::                GES:100 00:49:58
*N IA f000:1:2:a003::/64    fe80::250:56ff:fe97:44ee GES:100 00:50:45
```

5.58 Show OSPFv3 Setting

What is the purpose of this test?

Run this test to view the OSPFv3 setting and neighbor status.

When can you run this test?

Run this test to verify the Edge OSPFv3 configuration.

For instructions, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-70: Show OSPFv3 Setting

Troubleshoot OSPFv3 - Show OSPFv3 Setting

Show OSPFv3 setting and neighbor status

Area	Cost	Hello Timer	Dead Timer	Interface	MTU	Nbr Id	NSM Status	OSPF	Passive Interface
1	1	10	40	GE5	1380	1.1.1.2	Full	enabled	no

5.59 Dump Context Logging Information

What is the purpose of this test?

Context logging is per Linux thread logging infrastructure. This test lists the threads that use context logging.



Note: Release 5.1.0.0 integrates Context Logging exclusively for the Routing feature.

When can you run this test?

Run this test to dump the threads that utilize context logging.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

This test dumps the Thread Name, Thread ID, and Context Log Status (On or Off) for the thread that uses Context Logging.

- Context Log Status 'On' indicates that the system has activated context logging for the specified thread.
- Context Log Status 'Off' indicates that the system has deactivated context logging for the specified thread.

The following is an example of the test output:

Figure 5-71: Dump Context Logging Information

Dump Context Logging Information

Context Logging information for threads and its enabled/disabled status

Test Duration: 1.001 seconds

Thread Name	Thread ID	Context Log Status
edged	10879	On
edged_ev_thr	11882	On
link_fm	11481	On
path_state_fm	11479	On
vcomp_ctl_0	14308	On
vcomp_ctl_1	14309	On
MgtEventReceiver	14273	On

5.60 Enable or Disable Context Logging

What is the purpose of this test?

Context logging is per Linux thread logging infrastructure.

**Note:** Release 5.1.0.0 integrates Context Logging exclusively for the Routing feature.

When can you run this test?

Run this test to activate or deactivate context logging for a specific thread or all threads.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

Specify a thread ID to activate or deactivate context logging for that thread, or use the **All** option. The action applies after running the test. Validate the changes using the **Dump Context Logging Information** test command.

The following is an example of the test output:

Figure 5-72: Enable or Disable Context Logging

Enable/Disable Context Logging

Enable/Disable Context Logging for given thread or all threads

Test Duration: 1.001 seconds

Thread ID

Context Log Enabled

Context Log action applied

5.61 Gateway

What is the purpose of this test?

To change the traffic path of cloud (Internet) traffic.

When can you run this test?


Run this test to change the path for data traffic to use Business policy, or to use Gateway Path (Multi-Path), or to go directly on the WAN Interface.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-73: Gateway Test Output



The screenshot shows a web interface for the 'Gateway' test. At the top, the title 'Gateway' is on the left and a 'RUN' button is on the right. Below the title, a note states: 'Choose whether cloud traffic should or should not use the Gateway Service. Note: This does not affect the routing of VPN traffic.' Underneath, there is a label 'Cloud Traffic Routing' followed by a dropdown menu currently set to 'Route per Business Policy (default)'. In the bottom right corner of the configuration area, it says 'Test Duration: 1.002 seconds'. A large text box at the bottom displays the test output: 'Cloud traffic will now be routed according to business policy'.

5.62 HA Info

What is the purpose of this test?

To know more about the HA device, IP, Link, Status, and connection information.

When can you run this test?

Run this test to view the basic and interface information of Active and Standby Edges in a High Availability setup.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output: Standard HA

Figure 5-74: HA Info Test Output

HA Info

Show basic and interface information of active and standby edges when HA is enabled

Active and Standby Edge Info

Edge Type	Edge Serial Number	LAN count	WAN count
ACTIVE	1KXGPK2	1	3
STANDBY	4PHJPK2	1	3

Active and Standby Interfaces

Logical Name	Interface IP	Nexthop IP	Interface IP6	Nexthop IP6	Interface State (Active)	Interface State (Standby)
SFP1	0.0.0.0	0.0.0.0	::	::	LOCAL_DOWN	LOCAL_DOWN
GE5	192.168.111.2	0.0.0.0	::	::	LOCAL_UP	LOCAL_UP
GE3	192.168.161.246	192.168.161.245	::	::	LOCAL_UP	LOCAL_UP
GE4	192.168.161.250	192.168.161.249	::	::	LOCAL_UP	LOCAL_UP
SFP2	0.0.0.0	0.0.0.0	::	::	LOCAL_DOWN	LOCAL_DOWN
GE6	0.0.0.0	0.0.0.0	::	::	LOCAL_DOWN	LOCAL_DOWN

Figure 5-75: Enhanced HA Test Output

Test Duration

Active and Standby Edge Info

Edge Type	Edge Serial Number	No. of LANs	No. of WANs
ACTIVE	65H5V43	1	1
STANDBY	D9J5V43	1	1

Active and Standby Interfaces

Logical Name	Interface IP	NextHop IP	Interface State (Active)	Interface State (Standby)
SFP1	0.0.0.0	0.0.0.0	LOCAL_DOWN	LOCAL_DOWN
GE5	0.0.0.0	0.0.0.0	LOCAL_DOWN	LOCAL_DOWN
SFP2	0.0.0.0	0.0.0.0	LOCAL_DOWN	LOCAL_DOWN
GE3	192.168.15.2	192.168.15.1	LOCAL_UP	LOCAL_DOWN
GE4	10.48.146.82	10.48.146.81	USE_PEER	USED_BY_PEER
GE6	0.0.0.0	0.0.0.0	LOCAL_DOWN	LOCAL_DOWN

5.63 List Clients

What is the purpose of this test?

To display the DHCP lease expiry and the interfaces connecting the client to the Edge.

When can you run this test?

Run this test to verify if the clients are receiving the correct DHCP address.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-76: List Clients

Address	MAC Address	Hostname	Lease Expiry (UTC)	Wireless Connection
LAN VLAN1				
10.0.2.25	00:50:56:9c:5a:1f			
LAN VLAN100				
10.100.2.100	00:50:56:9c:5a:1f			
LAN VLAN101				
10.101.2.100	00:50:56:9c:5a:1f			

1. The diagnostic output displays the LAN client IP and MAC addresses during the DHCP process. If the list omits these details, restart the DHCP service and re-run the test.
2. Run this test to verify bogus devices in the LAN device.

5.64 List Paths

What is the purpose of this test?

To check the active tunnel paths between local WAN links and each peer, and the Gateway status.

When can you run this test?

Run this test when experiencing site-to-site communication or Gateway traffic issues to check if the tunnel is UP to the destination.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-77: List Paths

List Paths

View the list of active paths between local WAN links and each peer.

Peer

b3-edge1

Include Sub Paths

☐

Test Duration: 1.002 seconds

WAN Link	Local IP	Remote IP	State	VPN	Bandwidth (tx/rx)	Latency (tx/rx)	Jitter (tx/rx)	Loss (tx/rx)	Bytes (tx/rx)	Uptime	Mode
169.254.9.9	169.254.9.9	169.254.6.65	STABLE	UP	255.83 Mbps	0 ms	0.0 ms	0.0%	9.95 MB	22h48m46s	STATIC
					268.36 Mbps	0 ms	0.0 ms	0.0%	9.95 MB		
1900.2.1.1:2	1900.2.1.1:2	1900.3.1.2:2	STABLE	UP	257.06 Mbps	0 ms	0.0 ms	0.0%	13.37 MB	22h48m46s	STATIC
					265.71 Mbps	0 ms	0.0 ms	0.0%	13.38 MB		
1900.2.1.1:2	1900.2.1.1:2	1900.3.1.1:2	STABLE	UP	257.06 Mbps	0 ms	0.0 ms	0.0%	13.38 MB	22h48m46s	STATIC
					265.71 Mbps	0 ms	0.0 ms	0.0%	13.38 MB		
169.254.9.9	169.254.9.9	169.254.6.57	STABLE	UP	255.83 Mbps	0 ms	0.0 ms	0.0%	19.24 MB	22h48m46s	STATIC
					268.36 Mbps	0 ms	0.0 ms	0.0%	18.78 MB		

The Remote Diagnostics output displays the following information:

Table 7: Remote Diagnostics - Options and Descriptions

Option	Description
WAN Link	Specifies the WAN link IP that establishes the tunnel.
Local IP	Specifies the Physical Interface IP for the WAN link.
Remote IP	Specifies the Peer IP that anchors the tunnel.
State	Specifies the tunnel state. The state can be any of the following: - Stable - Tunnel is up and stable. - Unstable - Tunnel is experiencing packet loss, jitter, or latency. Check the output to find the cause for the unstable tunnel. - BW_Measurement - In this state, both peers negotiate a tunnel between them. - Quiet - The tunnel shows no active traffic flow. Anything other than "Stable" indicates an issue with the WAN link.
VPN	Specifies the VPN state, and it should be UP for a good tunnel.
Bandwidth (tx/rx)	Indicates the bandwidth of the tunnel.
Latency (tx/rx)	Indicates the latency of the tunnel.
Jitter (tx/rx)	Indicates the jitteriness of the tunnel.
Loss (tx/rx)	Indicates the packet loss of the tunnel.
Bytes (tx/rx)	Indicates the bytes of the tunnel in MB.
Uptime	Indicates the duration of tunnel uptime.
Mode	Specifies the mode of the tunnel: - Static - Static tunnels are always UP. - Dynamic - Dynamic tunnels facilitate B2B communication by establishing connections on a need basis.

5.65 MIBs for Edge

What is the purpose of this test?

To retrieve the VeloCloud SD-WAN and Edge MIBs that the specific Edge supports.

When can you run this test?

Run this test to download MIB dump file by selecting the **MIBs for Edge** button.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-78: MIBs for Edge

MIBs for Edge

Dump Edge MIBs.

VELOCLOUD-MIB: the root MIB of all VeloCloud specified MIBs and required for installing VELOCLOUD-EDGE-MIB.

VELOCLOUD-MIB-EDGE: the MIB specified for Edge device.

MIB VELOCLOUD-MIB ▾

```
-----
-- VMware SD-WAN MIB Definitions --
--                                     --
-- Contains:                          --
--   .velocloud(45346)                --
--     .orchestrator(1)               --
--     .edge(2)                       --
--     .gateway(3)                    --
--                                     --
-----

VELOCLOUD-MIB DEFINITIONS ::= BEGIN

IMPORTS
    MODULE-IDENTITY, enterprises      FROM SNMPv2-SMI
;

velocloud MODULE-IDENTITY
    LAST-UPDATED      "202105110000Z"
    --
```

Copy and save the output in *.mib* format so an SNMP server can poll the Edge for data.

5.66 NTP Dump

What is the purpose of this test?

Run this test to verify the date, time, and NTP server details used by the Edge.

When can you run this test?

Run this test if users have issues with the date and time in logs and the system time. The system uses UTC timestamps to maintain a consistent reference point across globally distributed networks. For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-79: NTP Dump

NTP Dump

RUN

Current date/time on Edge and NTP information

Test Duration: 1.002 seconds

Edge	
Date/Time	Thu May 26 06:36:01 UTC 2022
NTP	
System Peer	0.0.0.0
System Peer Mode	unspec
Leap Indicator	11
Stratum	16
Precision	-24
Root Delay	0.000
Root Dispersion	0.000
Reference ID	.
Reference Time	(no time)
System Jitter	0.000000
Clock Jitter	0.000
Clock Wander	0.000
Broadcast Delay	-50.000
Auth Delay	0.000

In the output, check the following:

1. Verify that the date and time are correct in UTC format.
2. Verify that the system peer matches the one mentioned in the NTP configuration.
3. The Leap Indicator indicates if an impending leap second is to be inserted or deleted in the last minute of the current day. Therefore, if the leap second occurs, the NTP client running is one second ahead or the seconds mentioned in the leap indicator than the actual time.
4. Stratum is the distance between Edge and NTP server. Lesser the Stratum number closer the server is. If the Stratum number is above 16 then it is considered to be unsynchronized.

5. If the clock is unsynchronized, change the NTP server or PCAPs to determine whether the Edge receives the NTP sync request.

5.67 Reset USB Modem

What is the purpose of this test?

Run this test to reset the USB and CELL interface.

When can you run this test?

Run this test when the device does not detect USB or when USB cannot form tunnels. For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-80: Reset USB Modem



Verify the following:

1. Check if a Restart command has been issued.
2. Navigate to **Monitor > Edges > Device** configuration page for checking USB carrier and tunnel information for the respective port.

5.68 System Information

What is the purpose of this test?

The **System Information** command allows users to view the Edge's system load and Wide Area Network (WAN) stability statistics.

When can you run this test?


Run this test to view system information such as system load, recent WAN stability statistics, monitoring services details, and so on. The tunnel disconnects do not include the count of direct Internet Protocol Security (IPsec) connections. WAN stability statistics include the number of times individual Virtual Private Network (VPN) tunnels and WAN links lost connectivity for at least 700 milliseconds.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-81: System Information



5.69 Route Table Dump

What is the purpose of this test?

The Route Table Dump command lists the complete IPv4 routing table.

When can you run this test?

Run this test to verify the IPv4 Route in the Forwarding Information Base (FIB) table. Users can run the test by specifying any of the following options:

- Segment- Select the specific segment for which the user wants the system to display routes. Select "all" for all segments.
- Prefix- Specify the exact prefix for which the user wants the system to display routes.
- Routes- Select any of the following options from the drop-down menu:
 - all- Display all the routes for every prefix.
 - preferred- Display the preferred route alone for each prefix (the route used for data forwarding).

 **Note:** The Route Table Dump command output has a limit of 16000 routes.

Figure 5-82: Route Table Dump

Table 8: Remote Diagnostics Field Descriptions

Field	Description
Address	Specifies the IPv4 routes available in the table.
Segment	Specifies the segment in which the routes are available and handled by the Edge.
Netmask	Specifies the range of IPv4 addresses .
Type	Specifies the route type, such as Cloud, Edge2Edge, any (Underlay or Connected), and so on.
Cost	Specifies the route cost or metric used in the selection of route criteria.
Preference	Specifies the route preference.
Order	Specifies the order of the route.
Reachable	Specifies whether the route is Reachable (True) or Not Reachable (False).
Next Hop	Indicates the local exit interface for local routes. For overlay/remote routes, it indicates the type of next hop. For example, "Cloud gateway" for cloud routes, "Cloud VPN" for data center routes, or "edge to edge" routes, etc.
Next Hop Name	Specifies the name of the next hop device.
Destination Name	Specifies the name of the destination device.
Lost Reason	Specifies the code for the reason why a route loses the routing preference calculation logic to the next preferred route, on both Edges and Gateways.
(Not) Reachable Reason	Specifies the reason for the route being reachable or not reachable.



Note: An unresolved route learnt via multi-hop Border Gateway Protocol (BGP) might point to an intermediate interface.

The following table lists the reason codes for an Edge and the corresponding descriptions:

Table 9: Reason Codes

Reason Code	Description
PR_UNREACHABLE	For overlay routes, the remote peer, whether Gateway or Edge, is unreachable.
IF_DOWN	The egress interface is down.
INVALID_IFIDX	The egress interface if-index for this route is invalid.
SLA_STATE_DOWN	The state given by IP SLA tracking is down.
HA_STANDBY	When the local Edge is a Standby, the system marks all routes synced from the active as reachable for operational convenience.
LOCAL_MGMT	Management routes are always reachable.
LOOPBACK	Loopback IP address is always reachable.
SELF_ROUTE	Self IP routes are always reachable.
RECUR_UNRES	The system marks recursive routes as reachable to enable recursive resolution, which provides greater operational convenience.
VPN_VIA_NAT	VPN via NAT routes are always reachable.
SLA_STATE_UP	The state given by IP SLA tracking is up.
IF_RESOLVED	The egress interface is up and resolved.
PR_REACHABLE	For overlay routes, the remote peer, whether Gateway or Edge, is reachable.
LR_NO_ELECTION	Best route.
LR_NP_SWAN_VS_VELO	The predecessor is selected because it is a non-preferred static WAN route (configured with the preferred flag set to false), whereas the current route is a via VeloCloud route.
LR_NP_SWAN_VS_DEFRT	The predecessor is selected because it is a non-preferred static WAN route compared to the current default route.
LR_NP_ROUTE_TYPE	The predecessor is selected because its route type is better than the current route. Also, one of the compared routes is a non-preferred route.
LR_BGP_LOCAL_PREF	Both routes are learnt using BGP. The predecessor is selected because it has a higher local preference than the current route.
LR_BGP_ASPATH_LEN	Both routes are learnt using BGP. The predecessor is selected because its Authentication Server (AS) path value is lower than the current route's.
LR_BGP_METRIC	Both routes are learnt using BGP. The predecessor is selected because it has a lower metric value than the current route.
LR_EXT_OSPF_INTER	The predecessor is selected because it is a route learnt via Open Shortest Path First (OSPF) with an intra- or inter-area metric, whereas the system learns the current route via BGP.
LR_EXT_BGP_RT	The predecessor is selected because it is a BGP-learned route, whereas the current route is an OSPF-learned route with metric type OE1 or OE2.
LR_EXT_METRIC_TYPE	Both routes are OSPF routes. The predecessor is selected because its metric type is better than the current route's. Order of preference for OSPF metric types: OSPF_TYPE_INTRA, OSPF_TYPE_INTER, OSPF_TYPE_OE1, OSPF_TYPE_OE2.
LR_EXT_METRIC_VAL	Both routes are OSPF routes. The predecessor is selected because it has a lower metric than the current route.
LR_EXT_NH_IP	Both routes are OSPF Equal Cost Multipath (ECMP) routes. The current route is lost to the predecessor since it was learnt later.
LR_PG_BGP_ORDER	Both are remote BGP routes with the same BGP parameters. The current route is selected because it is a Partner Gateway (PG) route and has a lower "order" value than the current route.
LR_NON_PG_BGP_ORDER	Both are remote BGP routes with same BGP parameters. The current route is selected because it is a non-PG route and has a lower "order" value than the current route.

Reason Code	Description
LR_EXT_ORDER	Both are remote OSPF routes with same metric. The predecessor is selected because it has a lesser order value than the current route.
LR_PREFERENCE	Both are either BGP or OSPF routes. The predecessor is selected because it has a lesser preference value than the current route.
LR_DCE_NSD_STATIC_PREF DCE-Data center, NSD-Non-SDWAN site	Both are local NSD static routes. The predecessor is selected because it is the preferred route (the preferred flag is set to true), whereas the current route is non-preferred.
LR_DCE_NSD_STATIC_METRIC	Both are NSD static routes. The predecessor is selected because it has a lesser metric value than the current route.
LR_DCE_NON_REMOTE	Both are NSD static routes. The predecessor is selected because it is a local route (non-remote), and the current route is remote.
LR_DCE_NSD_STATIC_REMOTE_ORDER	Both are remote NSD static routes. The predecessor is selected because it has a lower order value than the current route.
LR_DCE_DC_DIRECT	Both are NSD static routes. The predecessor is selected because its DC_DIRECT flag is set, and the current route does not have this flag set. This is the route with "n-nonVeloCloud" flag set in the debug.py--routes output. These are routes learnt from an NVS from Edge.
LR_DCE_LOGICAL_ID	Both are NSD static routes. The predecessor is selected because its logical ID is better than the current route's.
LR_NETMASK	The predecessor is selected because it has a higher netmask than the current one. This will not hit, since the netmask is different; it is a separate network/route entry.
LR_NETADDR	The predecessor is selected because its network address is higher than the current one. This will not hit, since the network address is different; it is a separate network/route entry.
LR_CONN_FLAG	The predecessor is selected because it is a connected route, and the current route is not a connected route.
LR_SELF_FLAG	The predecessor is selected because it is a self-route, and the current route is not a self-route.
LR_SLAN_FLAG	The predecessor is selected because it is a static LAN route, and the current route is not a static LAN route.
LR_SWAN_FLAG	The predecessor is selected because it is a static WAN route, and the current route is not a static WAN route.
LR_NSD_STATIC_LOCAL	The predecessor is selected because it is a local NSD static route, and the current route is an NSD BGP route.
LR_NSD_BGP_VS_NON_PREF_STATIC	The predecessor is selected because it is an NDS BGP route, and the current route is a local NSD static non-preferred route.
LR_NSD_STATIC_PREF_VS_NSD_STATIC	The predecessor is selected because it is an NSD static preferred route, and the current route is not an NSD static route.
LR_CONN_STATIC_VS_NSD_BGP	The predecessor is selected because it is a remote connected/static route, and the current route is an NSD BGP route.
LR_OPG_SECURE_STATIC	The predecessor is selected because it is a PG secure static route, and the current is not.
LR_ROUTED_VS_VELO	The predecessor is selected because it is a route learnt from routing protocols, unlike the current route, which is a "v- ViaVeloCloud" route.
LR_INTF_DEF_VS_ROUTED	The predecessor is selected because it is the default cloud route when compared to the current route, which is a route learnt using routing protocols (local or remote).
LR_ROUTE_TYPE	The predecessor is selected because its route is better than the current one.
LR_E2DC_REMOTE	The predecessor is selected because it is an Edge2DC route, and it is a local route, and the current route is remote.

Reason Code	Description
LR_CONNECTED_LAN	Both are connected routes. The predecessor is selected because it is a connected LAN route, and the current route is not a connected LAN route.
LR_VELO_REMOTE_FLAG	Both are cloud routes. The predecessor is selected because it is a remote route when compared to the current, which is a local cloud route.
LR_VELO_EdgeD_ROUTED	Both are cloud routes. The predecessor is selected because it is a route learnt via a routing protocol, and the current route is not learnt via a routing protocol.
LR_VELO_PG_ROUTE	Both are cloud routes. The predecessor is selected because it is a PG route, and the current route is not a PG route.
LR_VIA_VELO_ROUTE	Both are cloud routes. The predecessor is selected because it is a via VeloCloud route, and the current is not a via VeloCloud route.
LR_REMOTE_NON_ROUTED	Both are remote (overlay) routes. The predecessor is selected because it is a route not learnt via a routing protocol (static/connected), and the current route is a route learnt via a routing protocol.
LR_REMOTE_DCE_FLAG	Both are remote (overlay) routes. The predecessor is selected because it is a data center Edge route ("D- DCE" is set in the debug.py--routes output), and the current is not a data center Edge route.
LR_METRIC	The predecessor is selected because its metric is lower than the current route's.
LR_ORDER	The predecessor is selected because it has a lower order than the current route.
LR_LOGICAL_ID	The predecessor is selected because its logical ID is better than the current route's.
LR_EXT_BGP_VIA_PRIMGW	Both are BGP routes. The predecessor is selected because it is an NSD BGP route learnt from the primary NSD Gateway. The system learned the current route from a redundant NDS Gateway,

The following table lists the reason codes for a Gateway and the corresponding descriptions:

Table 10: Reason Code Descriptions

Reason Code	Description
LR_NO_ELECTION	Best route.
LR_NVS_STATIC_PREF	The predecessor is selected because it is an NVS static route, and the current route is not.
LR_EXT_BGP_VS_OSPF	The predecessor is selected because it is a BGP route, and the current route is an OSPF route with metric type OE1/OE2.
LR_EXT_BGP_ROUTE	Both are cloud routes. The predecessor is selected because it is a BGP learnt cloud route, and the current route is not (it is static).
LR_CLOUD_ROUTE_VS_ANY	The predecessor is selected because it is an Edge2Edge or Edge2Datacenter route, and the current route is a cloud static route. Edge2Edge/Edge2Datacenter > Cloud static.
LR_BGP_LOCAL_PREF	Both are either Edge2Edge or Edge2Datacenter routes learnt via BGP. The predecessor is selected because it has a higher local preference value than the current route.
LR_BGP_AS_PATH_LEN	Both are either Edge2Edge or Edge2Datacenter routes learnt via BGP. The predecessor is selected because its AS path value is lower than the current route's.
LR_BGP_METRIC	Both are either Edge2Edge or Edge2Datacenter routes learnt via BGP. The predecessor is selected because it has a lower metric value than the current route.
LR_DCE_NSD_STATIC_PREF	Both are Edge2Datacenter routes. The predecessor is selected because it is an NSD static route, and the current route is not.
LR_DCE_NSD_STATIC_METRIC	Both are Edge2Datacenter static routes. The predecessor is selected because its metric value is less than that of the current route.
LR_DCE_NSD_STATIC_GW_NON_REMOTE	Both are Edge2Datacenter static routes. The predecessor is selected because it is a local route, and the current is a remote route.
LR_DCE_LOGICAL_ID	Both are Edge2Datacenter static routes. The predecessor is selected because it is a local route, and the current is a remote route.
LR_E2DC_METRIC	Both are Edge2Datacenter routes. The predecessor is selected because its metric is less than that of the current route.
LR_DC_IPADDR	Both are Edge2Datacenter routes. The predecessor is selected because its data center IP address is lower than the current route's.
LR_E2DC_NETADDR	Both are Edge2Datacenter routes. The predecessor is selected because its network address is lower than that of the current route.
LR_E2E_PREFERENCE	Both are Edge2Edge routes. The predecessor is selected because its preference value is lower than the current route's.
LR_E2E_METRIC	Both are Edge2Edge routes. The predecessor is selected because its metric value is less than the current route.
LR_E2E_LOGICAL_ID	Both are Edge2Edge routes. The predecessor is selected because its logical ID is better than the current route's.
LR_E2E_NETADDR	Both are Edge2Edge routes. The predecessor is selected because its network address is lower than the current route's.
LR_OPG_SECURE_STATIC	The predecessor is selected because it is a PG secure static route, and the current route is not a PG secure static route.
LR_ROUTE_TYPE	The predecessor is selected because its route type is better than the current route's.
LR_NETMASK	The predecessor is selected because it has a higher netmask than the current route.
LR_METRIC	The predecessor is selected because it has a lower metric value than the current route.
LR_PREFERENCE	Both are routes learnt from routing protocols. The predecessor is selected because it has a lesser preference value than the current route.
LR_NETADDR	The predecessor is selected because its network address is lower than the current route's.

Reason Code	Description
LR_LOGICAL_ID	The predecessor is selected because its logical ID is better than the current route.

5.70 VPN Test

What is the purpose of this test?

The VPN Test command allows users to view the Virtual Private Network (VPN) Branch-to-Branch Connectivity between the Edges.


When can you run this test?

Run this test if the data traffic between the Branches or between the Hub and Spoke is not bi-directional. For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-83: VPN Test



The screenshot shows a web interface for the 'VPN Test'. At the top, there's a title 'VPN Test' and a 'RUN' button. Below the title, it says 'Use ping to test VPN connectivity to each peer.' and 'Segment Global Segment'. On the right, it says 'Test Duration: 3.002 seconds'. The main part of the interface is a table with the following data:

Edge Name	Destination	Result	Latency(millisecs)
b3-edge1	fd00:3:1::1	Pass	3
b1-edge1	10.0.1.1	Pass	4
b3-edge1	1.3.0.1	Pass	3

This **Remote Diagnostics** test will perform the VPN test by confirming the tunnel status between the Edges, and the output displays the following information:

Table 11: Remote Diagnostics Field Descriptions

Field	Description
Edge Name	Specifies the name of the peer Edge.
Destination	Specifies the logical ID of the destination device.
Result	The result displays one of the following: - Pass - Tunnels and traffic between the Edges are up and running. - Fail - Tunnels and traffic between the Edges are down.
Latency (milliseconds)	Specifies the latency in milliseconds.

5.71 WAN Link Bandwidth Test

What is the purpose of this test?

The **WAN Link Bandwidth Test** command measures the Bandwidth on a specific link.

When can you run this test?


Run this test if you want to verify the bandwidth of the WAN Link. If the link measured the wrong or inaccurate bandwidth incorrectly, you can run this test to measure it again.

For instructions on how to run a remote diagnostic test on Edges, see [Run Remote Diagnostic Tests on Edges](#).

What to check in the test output?

The following is an example of the test output:

Figure 5-84: WAN Link Bandwidth Test



The screenshot shows a web interface for the 'WAN Link Bandwidth Test'. At the top, the title 'WAN Link Bandwidth Test' is displayed next to a blue 'RUN' button. Below the title, a subtitle reads 'Force a re-test the bandwidth of a WAN link.' There is a dropdown menu labeled 'WAN Link' with the value '169.254.9.9' selected. In the bottom right corner, it says 'Test Duration: 1.001 seconds'. A message box at the bottom states: 'Bandwidth test has been queued. The measured rates will be updated on the Overview page when results are available.'


Perform Remote Actions

Users can perform actions such as restarting services, rebooting, or deactivating Edge remotely from the Enterprise portal. The Orchestrator permits remote actions only on Edges in a **Connected** state.

To perform remote actions:

1. In the **Enterprise** portal, select the **Shortcuts** option available on the **Configure > Edges** or **Monitor > Edges** pages.
See the topics *Configure Edge Overrides* and *Monitor Edges*, in the *Arista VeloCloud Administration Guide*.
2. In the **Shortcuts** menu, select **Remote Actions** to open the **Remote Actions** dialog.

Figure 6-1: Remote Actions



3. Perform the following actions:

Table 12: Remote Actions and Descriptions

Action	Description
Identify	Randomly flash lights on the selected Edge to identify the device.
Restart Service	Restart the VeloCloud SD-WAN services on the selected Edge.
Reboot	Reboot the selected Edge.
Shutdown	Power off the selected Edge. To restore the Edge, remove the power cable, and then plug it back into the Edge.
Deactivate	Reset the device configuration to its factory default state.
Force HA Failover	Force HA Failover. This option appears only when the Edge operates in a High Availability configuration with an HA Ready status.



Note: The actions may take up to a minute to run on the device.

Diagnostic Bundles for Edges

Diagnostic bundles allow Operator users to collect all configuration and log files into a single zipped file. Diagnostic bundles contain the necessary information to facilitate troubleshooting and debugging.

To generate and download Diagnostic Bundles:

1. In the **Enterprise** portal, select the **Diagnostics** tab.
2. Select **Diagnostic Bundles** to request the following bundles:
 - **Request PCAP Bundle**– The Packet Capture bundle is a collection of the packet data of the network. Operators, Standard Admins, and Customer Support can request PCAP bundles. For more information, see [Request Packet Capture Bundle for Edges](#).
 - **Request Diagnostic Bundle**– The Diagnostic bundle is a collection of all the configuration and logs from a specific Edge. Only Operators can request Diagnostic bundles. For more information, see [Request Diagnostic Bundle for Edges](#).



Note: Only an Operator user can access the **Request Diagnostic Bundle** option. A Partner user or an Enterprise user can request for a PCAP Bundle.

The **Diagnostic Bundles** window displays the generated bundles.

Figure 7-1: Diagnostic Bundles

	Request Status	Type	Edge	Reason for Generation	User	Generated Date	Cleanup Date
☐	Complete Download	PCAP	b1-edge1		super@velocloud.net	Nov 10, 2022, 3:34:53 PM	Jan 9, 2023
☐	In Progress	Diagnostics	b1-edge1		super@velocloud.net	Nov 10, 2022, 3:34:35 PM	Jan 9, 2023

3. To download the details of generated bundles, select **More > Download CSV**.
The Orchestrator generates a CSV file containing the requested details.

7.1 Request Packet Capture Bundle for Edges

The Packet Capture bundle collects network packet data. The user can utilize this data to analyze network characteristics and debug an Edge device.

To generate a PCAP bundle:

1. In the **SD-WAN** service of the **Enterprise** portal, select the **Diagnostics** tab.
2. Select **Diagnostic Bundles > Request PCAP Bundle**.
3. In the **Request PCAP Bundle** window, configure the following:

Figure 7-2: Request PCAP Bundle

Request PCAP Bundle

Target: b1-edge1

Interface: GE5

Duration: 5 seconds

Reason for Generation: Troubleshooting

PCAP FILTERS | ADVANCED FILTERS

IP2 is 10.0.0.1/32

IP: Port 1 is 80

+ CLEAR

CLOSE SUBMIT

Table 13: Request PCAP Bundle - Options and Descriptions

Option	Description
Target	Choose the target Edge from the drop-down menu. The Orchestrator collects packets from the selected Edge.
Interface	Choose an Interface or a VLAN from the drop-down menu. The Orchestrator collects packets from the selected Interface.
Duration	Choose the time in seconds. The Orchestrator collects packets for the selected duration.
Reason for Generation	Enter a reason for generating the bundle. This field is optional.
PCAP Filters	Define PCAP filters to control the generated packet data by selecting the following options: • IP1 - Enter an IPv4 address, IPv6 address, or Subnet mask. • IP2 - Enter an IPv4 address, IPv6 address, or Subnet mask. • IP1:Port1 - Enter a Port ID associated with IP1. • IP2:Port2 - Enter a Port ID associated with IP2. • Protocol - Select a protocol from the list. This field is optional.  Note: To use the PCAP filtering capability, define at least one filter.
Advanced Filters	Define free form filters to control the generated packet data. This field is optional.

The **Diagnostic Bundles** window displays the details of the generated bundle, including its status.

Packet Capture for Edges configured for High Availability

In Release 5.2.0 and later, a user can request a packet capture for the Standby Edge's HA interface, which connects the Standby Edge to the Active Edge. This option appears at the bottom of the menu and reads **Standby Edge**, and lists the HA interface.

Figure 7-3: Request PCAP Bundle for Standby Edge

Request PCAP Bundle

Target: B2 - 610

Interface: GE1 - HA

Duration:

Reason for Generation: e Standby Edge's HA

PCAP FILTERS: ADVANCED

IP2 is

IP1: Port 1 is

CLEAR

CLOSE SUBMIT

7.2 Request Diagnostic Bundle for Edges

A Diagnostic bundle is a collection of configuration files, logs, and related events from a specific Edge.

To generate a Diagnostic bundle:

1. In the **Enterprise** portal, select the **Diagnostics** tab.
2. Select **Diagnostic Bundles** > **Request Diagnostic Bundle**.

3. In the **Request Diagnostic Bundle** window, configure the following:

Figure 7-4: Request Diagnostic Bundle for Edges

The screenshot shows a window titled "Request Diagnostic Bundle" with a close button in the top right corner. Inside the window, there are three main configuration areas: "Target" with a dropdown menu currently showing "b2-edge1"; "Reason for Generation" with a text input field containing "For Troubleshooting"; and "Core Limit" with a dropdown menu showing "No Limit" and an information icon. The "Core Limit" dropdown is open, displaying a list of options: "No Limit", "3" (which is highlighted in blue), "2", "1", and "No Cores". At the bottom right of the window, there are two buttons: "CLOSE" and "SUBMIT".

Table 14: Request Diagnostic Bundle - Options and Descriptions

Option	Description
Target	Select the target Edge from the drop-down menu. The Orchestrator collects data from the selected Edge.
Reason for Generation	Enter a reason for generating the bundle. This field is optional.
Core Limit	Select a value from the drop-down menu to reduce the size of the uploaded bundle when Internet connectivity is experiencing issues.

The **Diagnostic Bundles** window displays the details of the generated bundle, including its status. To download the generated bundle, see the topic *Request Diagnostic Bundle* in the *Arista VeloCloud Administration Guide*.

Diagnostic Bundles for Gateways

Run diagnostics for Gateways to collect diagnostic bundles and packet capture files for troubleshooting purpose. See the following topics:

- [Request Packet Capture Bundle for Gateways](#)
- [Request Diagnostic Bundle for Gateways](#)

8.1 Request Packet Capture Bundle for Gateways

The Packet Capture bundle collects network packet data. The user can utilize this data to analyze network characteristics, debug network traffic, and determine network status.

To generate a PCAP bundle:

1. In the **Operator** portal, select the **Gateway Management** tab, and then select **Diagnostic Bundles** in the left navigation pane.
The **Diagnostic Bundles** page appears with the existing diagnostic bundles.
2. To generate a new PCAP bundle, select **Request PCAP Bundle**.
3. In the **Request PCAP Bundle** dialog, configure the following details, and then select **Generate**.

Figure 8-1: Request PCAP Bundle

Request PCAP Bundle

All inputs are required unless otherwise indicated. A minimum of one filter should be defined.

Target: gateway-1

Connectivity: eth0

Duration: 5 seconds

Reason for Generation: Enter reason for generation (Optional)

PCAP FILTERS: IP2 is 10.0.0.0/32, IP2: Port 2 is 80

CLEAR, CLOSE, GENERATE

Table 15: Request PCAP Bundle - Options and Descriptions

Option	Description
Target	Choose the target Gateway from the drop-down menu. The Orchestrator collects packets from the selected Gateway.
Connectivity	Choose an Interface or an Edge ID from the drop-down menu. The Orchestrator collects packets from the selected Interface or Edge associated with the Gateway.
Duration	Choose the time in seconds. The Orchestrator collects packets for the selected duration. The default value is 5 seconds.
Reason for Generation	Enter a reason for generating the bundle. This field is optional.
PCAP Filters	Define PCAP filters to control the generated packet data by selecting the following options: - IP1 - Enter an IPv4 address, IPv6 address, or Subnet mask. - IP2 - Enter an IPv4 address, IPv6 address, or Subnet mask. - IP1:Port1 - Enter a Port ID associated with IP1. - IP2:Port2 - Enter a Port ID associated with IP2. - Protocol - Select a protocol from the list. This field is optional.  Note: To use the PCAP filtering capability, define at least one filter.
Advanced Filters	Define free form filters to control the generated packet data. This field is optional.

The **Diagnostic Bundles** window displays the details of the generated bundle, including its status.

- To download a generated bundle, select the link next to **Complete** in the **Request Status** column or select the bundle, and then select **Download Bundle**.
The Orchestrator downloads the bundle as a ZIP file.
- The Orchestrator automatically deletes the completed bundles on the date displayed in the **Cleanup Date** column. Select the **Cleanup Date** link or choose the bundle, and then select **More > Update Cleanup Date** to modify the date.
- To delete a bundle manually, select the bundle, and then select **Delete**.

8.2 Request Diagnostic Bundle for Gateways

Diagnostic bundles allow Operator users to collect all configuration and log files into a single zipped file. Diagnostic bundles contain the necessary information to facilitate troubleshooting the Gateways.

An Operator Superuser and Operator Admin user can create, manage, download, and delete diagnostic bundles for Gateways created by both Operator and Partner users.



Note: Operator Business Specialist user and Operator IT support users can only view the generated Diagnostic bundles and download the CSV file.

Partner Superuser and Admin with an activated Gateway management access can create, manage, and delete diagnostic bundles only for Gateways created by a Partner or a Partner-managed Gateway created by the Operator. The Partner IT support users can only view the generated Diagnostic bundles and download the CSV file.

Note:

- The Partner Business Specialist role lacks the permissions required to use the **Diagnostic Bundles** feature.
- The **Request Diagnostic Bundle** and **Download Bundle** options are available only for Partners with an activated Gateway management access. Deactivating Gateway management access limits Partners to viewing generated bundles and downloading the CSV file. To request Gateway Management access, Partners must contact the Operator Superuser.

To generate a new Diagnostic bundle:

1. In the **Orchestrator**, select the **Gateway Management** tab, and then select **Diagnostic Bundles** in the left navigation pane.
The **Diagnostic Bundles** page appears with the existing diagnostic bundles.
2. To generate a new Diagnostic bundle, select **Request Diagnostic Bundle**.
3. In the **Request Diagnostic Bundle** dialog, configure the following details, and then select **Submit**.

Figure 8-2: Request Diagnostic Bundle for Gateways

Request Diagnostic Bundle

Target: gateway-1

Reason for Generation: For troubleshooting purpose

Core Limit: No Limit

CLOSE SUBMIT

Table 16: Request Diagnostic Bundle - Options and Descriptions


Option	Description
Target	Select the target Gateway from the drop-down menu. The Orchestrator collects data from the selected Gateway.
Reason for Generation	Enter a reason for generating the bundle. This field is optional.
Core Limit	Select a value from the drop-down menu to reduce the size of the uploaded bundle when Internet connectivity is experiencing issues.

The **Diagnostic Bundles** window displays the details of the generated bundle, including its status.

4. To search for a specific diagnostic bundle, enter a relevant search text in the **Search** box. For advanced search, select the filter icon next to the **Search** box to filter the results by specific criteria.
- **Download Diagnostic Bundle:** Download the generated Diagnostic bundles to troubleshoot an Edge. To download a generated bundle, select the link next to **Complete** in the **Request Status** column or select the bundle, and then select **Download Bundle**. The Orchestrator downloads the bundle as a ZIP file. Send the downloaded bundle to a Support representative for debugging the data.
 - **Delete Diagnostic Bundle:** The Orchestrator automatically deletes the completed bundles on the date displayed in the **Cleanup Date** column.

1. To modify the date, select the **Cleanup Date** link or choose the bundle, and then select **More > Update Cleanup Date**.

Figure 8-3: Update Cleanup Date



Update Cleanup Date

☒ Remove bundle on
05/17/2022

☐ Keep Forever

CANCEL SAVE

2. In the **Update Cleanup Date** dialog, choose the date to schedule the automatic deletion of the selected bundle.
3. Select **Keep Forever** to prevent the system from automatically deleting the bundle.
4. To delete a bundle manually, select the bundle, and then select **Delete**.

References

This topic contains the following sections:

- [Related Documents](#)

A.1 Related Documents

Arista provides the following documentation for **VeloCloud SD-WAN**:

- *Arista VeloCloud SD-WAN Operator Guide*
- *Arista VeloCloud SD-WAN Administration Guide*
- *Arista VeloCloud SD-WAN Gateway Monitoring Guide*
- *Arista VeloCloud SD-WAN Orchestrator Deployment and Monitoring Guide*
- *Arista VeloCloud SD-WAN Partner Guide*
- *Arista VeloCloud SASE Global Settings Guide*
- *Arista VeloCloud SD-WAN Design Guide for Enhanced Firewall Services*
- *Arista VeloCloud SD-WAN 6.4 API*
- *Arista VeloCloud Portal API 6.4*